












Assembly Instructions

The recliner comes packaged in 3 boxes. Carefully remove all of components from the packaging and set aside for assembly.


CAUTION:
DO NOT use any sharp objects to open plastic wrapped components as damage to product or components may result.

Package Contents


Box1					
					
A*1 Chair Seat	B*1 Massage Remote	C*1 Plug	D*1 Power Source	E*1 Power Cord	F*2 Screw
		Box2	Box3		
					
G*2 Supporting Foot	H*1 Recline Remote	I*1 Chair Back	J*1 Left Armrest	K*1 Right Armrest	

Installation Instruction


STEP 1 : Find a small bag in the accessories box. Take out Screw(F) and Supporting Feet(G) from the small bag, Assemble the two Supporting Feet as shown on the bottom of mechanism to avoid toppling and falling.




STEP 2: Connect the Armrests (J&K) to the chair seat(A) by aligning the metal grooves and sliding down to the bottom.



STEP 3: Connect the chair back(I) to the chair seat(A) by aligning the metal grooves and sliding down to the bottom.





STEP 4 : Finally, connect the power supply and remote controllers as indicated in the diagram (B&C&D&E&H).



- Tips: 1. The connection plugs have different colors, black to black, white to white, red to red.
2. Plug both the **Power Cord(E)** and **Power Source(D)** into outlet to get the recliner working.

Operation Instruction



Note: Sitting on one side for extended periods can lead to uneven pressure distribution, resulting in deformation.

Warnings

1. Please check if the components of the chair are all included and can be used normally.
2. Assemble all components according to the instruction correctly before you connect the chair to the power.
3. Please **DO NOT** sit on the armrests or footrest to eliminate the risk of tipping over.
4. If the chair is damaged or doesn't match the website description, please send clear pictures of the product and label of the carton to our service team for further help.
5. If the recliner doesn't work, you may try the following measures for self-checking firstly:
 - a) Check if all the cables are connected;
 - b) Check if the light of transformer is on.

If the chair still doesn't work, please feed the information back to our customer service in time and we'll help you solve the matter as soon as possible

