



Assembly Instructions








General Assembly Guidelines

- I. Ensure that **all** parts and hardware are available before beginning assembly.
- II. **Fo**llow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. The main type of hardware used to assemble this product are: bolts and screws.
- V. Power tools should not be used to assemble this product.





- VI. Drill may be needed for securing product to wall.

Parts List



Hardware List


A		Ø1/4"x5/8"mm	Bolt	8 pcs
B		Ø1/4"x1-1/8"mm	Bolt	14 pcs
C			Flat washer	14 pcs
D			Lock washer	14 pcs
E		4mm	Hex key	1 pc




Philips head screwdriver required for assembly
(not included)

*The hardware quantities listed above are required for proper assembly.
Some extra hardware may also have been included.*


Step 1




Step 2



Step 3



Step 4



Final Assembly