

Installation & Remote Control Guide

1. Wiring Instructions

This light fitting is straightforward to install. Only the **Live (L)** and **Neutral (N)** wires need to be connected.

The LED driver (white box) is clearly marked with the L and N terminals.

All other internal wires have already been connected in the factory.

No additional wiring or adjustments are required.

Once the Live and Neutral wires are connected correctly, the fitting is ready for use.

2. Using the Remote Control

Important: After installation, the light must first be switched on using the wall switch.

The remote control will not operate the light immediately after installation. It must be paired with the light during first-time setup.

3. Pairing the Remote Control (First-Time Setup)

Please follow these steps:

Turn on the light using the wall switch.

Within **5–10 seconds**, press and hold the **“SETUP”** button on the remote control.

The light will flash three times, confirming that pairing has been successful.

Once paired, the remote control can be used normally.