




























ASSEMBLY INSTRUCTION




















ITEM:Kitchen Island Cart

N707P537783





18
25
21
2
1
23
22
13
17
9
4
13
8
14
19
12
7
14
9
10
20
19
6
5
3
10
11
16
27
28
26
15
x3


 ① x 1	 ② x 1	 ③ x 1	 ④ x 1	 ⑤ x 1
 ⑥ x 1	 ⑦ x 1	 ⑧ x 1	 ⑨ x 2	 ⑩ x 2
 ⑪ x 1	 ⑫ x 1	 ⑬ x 2	 ⑭ x 2	 ⑮ x 3
 ⑯ x 3	 ⑰ x 1	 ⑱ x 1	 ⑲ x 2	 ⑳ x 1
 ㉑ x 1	 ㉒ x 1	 ㉓ x 1	 ㉕ x 2	 ㉖ x 3
 ㉗ x 3	 ㉘ x3			


A  36PCS	B  36PCS	C 6x30mm  32PCS	D M4x35mm  24PCS	E M5x35mm  4PCS
F M4x12mm  42PCS	G M3x12mm  26PCS	H M4x12mm  20PCS	I M6x45mm  4PCS	J M4x20mm  10PCS
K  1PC	L  5PCS	M  8PCS	N  4PCS	O  3PCS
P  1PC	Q  18PCS	R  3PCS	S  2PCS	CL  3PCS
CR  3PCS	DL  3PCS	DR  3PCS		


"B" Hardware installation example



1.








G	CL	CR
		
12PCS	3PCS	3PCS


2.



A


8PCS

3.




B	C
4PCS	4PCS

4.




B	C
4PCS	4PCS

5.




A



4PCS

6.




B



2PCS


7.




B


2PCS

8.




K	E
	
1PC	4PCS

9.




I	K
4PCS	1PC

10.




C	D
12PCS	12PCS

11.




H	R	S
20PCS	3PCS	2PCS

12.



F	N
12PCS	4PCS


13.




F

12PCS

14.




15.




A	F	O
12PCS	9PCS	3PCS

16.




B	C
12PCS	12PCS

17.




M	G	P
8PCS	2PCS	1PC


18.



B	D	G	A	DL	DR	J	L
12PCS	12PCS	12PCS	12PCS	3PCS	3PCS	6PCS	3PCS

19.






20.

180°






Q



18PCS


21.

When the No. 14 plate is pushed into, it should be aligned with the upper and lower slots, with the drawing surface facing outward and the smooth surface facing inward





22.

When the No. 14 plate is pushed into, it should be aligned with the upper and lower slots, with the drawing surface facing outward and the smooth surface facing inward



23.






F

9PCS

24.

180°



J	L
	
4PCS	2PCS

25.

