


USER'S MANUAL

BED







EN | ES

Contact us first if you have any problem.

Replacement for missing, damaged parts, we will ship its ASAP!


Hardware List

 M8 A X 4	 M6 × 15 B X 16	 M6 × 55 C X 3	 M8 × 40 E X 8	 Ø8 F X 8
 M6 × 35 G X 6	 H X 1	 I X 1	 M6 × 70 J X 16	 Ø6 K X 16
 M6 × 20 L X 12				



STEP 1

M6 × 70



(J) X 8


Ø6



(K) X 8



(H) X 1



STEP 2


M6 × 15



(B) X 6




(H) X 1



STEP 3

M6 × 20




(L)

X 6



(H)

X 1



STEP 4

M6 × 70



(J)

X 8

Ø6




(K)

X 8



(H)

X 1



STEP 5


M6 × 15



(B) X 6




(H) X 1



STEP 6


M6 × 20



(L) X 6



(H) X 1



PRODUCT ASSEMBLY

STEP 7

M8



X 4

M8 × 40




X 8

Ø8





X 8



X 1



X 1




10


PRODUCT ASSEMBLY

STEP 8


M6x35



X 4



X 1



11

STEP 9

M6x15




(B) X 4



M6x55



(C) X 2




(H) X 1




STEP 10

M6x35




(G) X 2


M6x55




(C) X 1



(H) X 1



STEP 11



STEP 12

