



# ASSEMBLY INSTRUCTIONS


---




**T-42DPT AND T-30P**



**T-42DPT AND T-23B OR T-23B-36**



**T-42DPT AND T-27B**



**T-42DPT AND T-11B**

## BEFORE ASSEMBLY

Thank you for purchasing this quality product. This product has been designed for easy assembly and constructed for durability. All parts were checked prior to packaging to insure quality. Prior to beginning assembly, however, make sure all parts and hardware are included and free of obvious defect.

### IMPORTANT NOTE:




- Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched.
- Remove all wrapping material, including staples & packing straps before you start to assemble.
- DO NOT tighten all screws and bolts until completely assembled.
- Keep all hardware parts out of reach of children.

### WARNING:

Long exposure to rubber or soft plastic may cause a chemical reaction and damage the finish of your product. Protect the surface of the product with cloth if you are using any product with rubber feet or base.






## PART LIST T-42DPT

When unpacking, please be careful not to discard any parts with the packaging. Before continuing, please make sure you have all of the following parts:

| NO | Description | Qty | Sketch  | NO | Description    | Qty | Sketch  |
|----|-------------|-----|---|----|----------------|-----|---|
| A  | Top         | 1   |  | B  | Mounting Plate | 1   |  |
| C  | Wood Slide  | 2   |  |    |                |     |   |



## HARDWARE LIST



When unpacking, please be careful not to discard any parts with the packaging. Before continuing, please make sure you have all of the following hardware:

| NO | Description                        | Qty | Sketch  | NO | Description                        | Qty | Sketch  |
|----|------------------------------------|-----|---|----|------------------------------------|-----|---|
| 1  | Bolt<br>(M6 x 45mm)                | 12  |  | 2  | Small Flat Washer<br>(Φ6.5 x 13mm) | 4   |  |
| 3  | Large Flat Washer<br>(Φ6.5 x 19mm) | 8   |  | 4  | Lock Washer<br>(Φ6.5 x 11mm)       | 12  |  |
| 5  | Allen key<br>(M4 x 30mm x 110mm)   | 1   |  |    |                                    |     |   |

## STEP 1





Attach mounting plate (B) to the pedestal with bolts (1), and washers (2) and (4) as shown below. Tighten with Allen key (5).





## STEP 2

Carefully place the pedestal on the bottom side of the table top. Attach the top (A) to mounting plate (B) with bolts (1), and washers (4) and (3) as shown below. Tighten with Allen key (5).



### STEP 3

Hold the drop leaf, push and slide the wooden piece from underneath the table top. To lower the drop leaf, carefully hold the drop leaf with one hand and slide the wooden piece from underneath the table top towards the center of the top. Then, gently lower the leaf and place in the down position.

