




















ASSEMBLY INSTRUCTION

A  ×1	B  ×1	C  ×1	D  ×1	E  ×2	
F  ×4	G  ×4	H  ×2	I  ×2	J  ×4	
K  ×1	L  ×4	M  Screw 8×80 ×6	N  Screw 8×60 ×2	O  Screw 8×40 ×12	
P  Screw 8×20 ×36	Q  Allen Key M5 ×1	R  Washer 8×19 ×58	S  Nutsert ×2	T  Open Spanner ×1	
U  Rubber Root Ø40×120 ×12	V  Connector 120×40×40 ×8	W  Rubber Washer Ø40 ×12	X  Adjusting pin Ø40×115 ×2	Y  Jack-plug ×1	Z  Velcro strap ×10


STEP 1:




STEP 2:




STEP 3:




STEP 4:




STEP 5:




STEP 6:




STEP 7:




STEP 8:




STEP 9:




STEP 10:




STEP 11:




STEP 12:




STEP 13:




STEP 14:




STEP 15:



STEP 16:




Panel function



1. Turn on and off the machine: after the power is turned on, the key will turn on red, press the key for 3 seconds, the blue light will turn on, and press the key for 3 seconds to turn off. (If no operation is performed within 60 seconds in the power on or standby state, all the lights will turn off, and other functions will work normally, press any key to turn on.)
2. Mode key: Click this key to adjust the RGB light with light mode
3. Music mode: Click this button, the light can beat with the music rhythm.
4. Brightness - : Click this key to reduce the brightness of the lamp.
5. Brightness + : Click this button to increase the brightness of the lamp.
6. Wireless charging area: 15W Max.
7. Single color key: Click this key to adjust the lamp belt to a single color.
8. USB charging port: DC5V1A/2A (when charging single-port, the output power is 5V 2A, and when charging Type-C port simultaneously, the output power is 5V1A).
9. White/Bluetooth switch: Without Bluetooth speaker, this key is the white light button, click to light up, and click again to turn off. With Bluetooth speaker, long press to turn on the Bluetooth speaker power, and long press again to turn off the Bluetooth speaker power.
10. Type-C charging port: DC5V2A (single-port charging, the output power is 5V2A, and USB port charging at the same time, the output power is 5V 1A).

Installation



Parameter

Power input: DC12V 3A light with line Output: DC12V Wireless charging: 15W Max. USB-A+C: 10W Max.

Function

This product is a magic light control box, which can adjust various lighting effects and wireless charging functions according to user needs.

Maintenance guide

Before the machine needs to be repaired, please check the following answers in order to find the possible cause of the problem you have encountered, some simple checks or minimal adjustments you have made may solve the problem and return to normal operation, if you have questions about some inspection points, or can not solve the problem, please hand over to professional maintenance personnel to repair.

Problem	Solution
Can not boot	The power supply is not plugged in properly. If it is confirmed that there is a problem with the power supply, it is necessary to replace the switching power supply.
Key not working	If there is no problem with the power supply, there may be a problem with the control box. Please don't press too hard. Please check if there is any foreign object or water, please restart the machine and try again.