




Assembly Instructions & Care Guide

Illustrations in this guide are for reference only and may differ slightly from the actual product

CONTENT

Before You Start

Overview	01
Caution	01
Material Specifications	01
Three-section Side-mounted Rail	02-03

Installation Guide

Exploded Views	04
Component Parts	05
Hardware	05
Assembly Directions	06-07
Troubleshoot	08

Usage and Maintenance

Use and Care	09
--------------	----

Other

Help Center	10
-------------	----

Before You Start

Overview

- 1. Check and ensure you have received all packages and necessary parts.
- 2. Prepare adequate assembly space. We recommend using pads or cardboard to prevent the floor from scratches.
- 3. Read the instructions to familiarize yourself with the assembly requirements. Allow sufficient time and have someone available to assist you if needed.
- 4. Place all hardware on a soft surface for easy identification.
- 5. The seller is not responsible for any damage or injury caused by improper assembly or use.
- 6. If you need further assistance, please contact us through

Caution

- 1. Children must not assemble this product. During assembly, keep small parts away from children as swallowing or inhaling them could be fatal.
- 2. Do not allow children to stand, climb, or play on the product, as it may tip over and cause serious injury.
- 3. Keep plastic packaging bags away from children to prevent risks of suffocation.
- 4. Avoid sharp objects and corrosive chemicals to prevent product damage or personal injury

Material Specifications

Solid Wood

Natural grains, scars, and color variations are inherent in real wood, which contribute to its unique beauty. Slight color changes may occur under different lighting and angles, due to variations in wood grain and light intensity.

Marble and Engineered Stone

Each marble and engineered stone piece has a unique pattern. Due to the nature of the materials, the pattern may differ from the one you see when purchasing.


Install your new product with care, following the instructions step-by-step. Do not skip any steps. Care-fully distinguish between left and right components. Do not over-tighten screws or use power tools, as this may damage the product.

Tools You May Need


*You might need a screwdriver (+/-) to complete this assembly.



Persons and Time Needed For Assembly



Door Panel Adjustment Instruction




①

Front-to-Back Direction Adjustment:

Rotate the screws on the door hinges shown in the image. The door panel can be moved front-back.

Adjustment range: 4mm




②

Left-Right Direction Adjustment:

Rotate the screws on the door hinges shown in the image. The door panel can be moved left-right.

Adjustment range: 3mm



③


Up-Down Direction Adjustment:

Rotate the screws on the door hinges shown in the image. The door panel can be moved up-down.

Adjustment range: 4mm



Door Panel Adjustment Instruction

Common Door Panel Issues:




Installation Guide


Exploded Views




1. Install the screw rod




2. Tighten the screw rod clockwise




3. Pay attention to tightening the screw rod



4. Installation plate




5. Align the arrow of the eccentric component with the screw rod



6. Pay attention to aligning the arrow of the eccentric part with the screw rod

Installation Guide

① X1




Hardware

Ⓐ X4




Ⓑ X8



M4*25

Ⓒ X2




Assembly Directions

Step 1

A x2


B x4



Step 2


A x2

B x4



Assembly Directions

Step 2



SAFETY WALL STRAP INSTALLATION


Note: It is highly recommended to install this safety strap kit to prevent tipping, damage and/or injury.

1. Insert short screw (C) through Double hole iron sheet (B) and safety wall strap (E) and attach to top panel (part A) using philips head screwdriver.

2. Drill a 1 1/32" hole where you want to secure the unit. The drilled hole will be at the same height as the hole in top panel (part A) where the safety wall strap (E) is attached. Tap wall anchor (A) into the hole.

3. Insert long screw (D) through Double hole iron sheet (B) and safety wall strap (E) into wall anchor (A) using philips head screwdriver.

Note: This item is not intended for clothing storage use.



⚠ WARNING	
	Children have died from furniture tipover. To reduce the risk of furniture tipover: ALWAYS install tipover restraint provided. NEVER put a TV on this product. NEVER allow children to stand, climb or hang on drawers, doors or shelves. NEVER open more than one drawer at a time. Place heaviest items in the lowest drawers. This is a permanent label. Do not remove!

Finished!

Fantastic, we're nearly there! Please carry out the following checks:

1. Have you tightened all the screws?
2. Are the levelers aligned with and making contact with the ground?
3. Have you installed the anti-tipping kit?

Troubleshoot


Wood furniture	Door opening is not flexible	The furniture is not leveled	Use items to level the furniture
		The door hinges should be adjusted properly.	Adjust door hinges and apply lubricating oil.
	Inflexible opening of drawer	Overload or deformation	Reduce weight, adjust guide rails, lubricate
	Loose component connection	Loose hinges or screws	The poke part should be coated with an appropriate amount of 502 glue, then re-install or tighten the screws.
	Minor scratches	friction with hard o sharp objects	Use a brush to apply similar pigment ink along wood grain to the scratches, then wipe off the excess.
	Corrosive stains	Accidentally stained with chemical solvents such as nail polish, nail polish remover, ect.	Wipe them with a dry cotton cloth immediately

Possible Issues During Assembly:

- The two boards can't be aligned at he same level.




- Holes on the bards and poles are not aligned, so screws can't be installed.



Recommended Solution:

- Please sightly loosen all screws and adjust the bards. Because the diameter of the holes on the pipes 23 mm lager than that of bots, the position of the boards can be adjusted.



- If it is still doesn't work after adjustment, please contact us for more solutions.

Usage and Maintenance

Use and Care

- Leave it vacant for half a month before use, maintain good ventilation to eliminate any odor.
- Place items steadily, heavier items should be placed at the bottom to avoid tipping over. For high temperature or frozen items, please put a heat-resistant pad underneath.
- Do not directly push or drag hard objects on the furniture to avoid scratching the surface.
- Avoid prolonged exposure to sunlight or heat sources to prevent discoloration or fading.
- Pay attention to moisture prevention to avoid mold. Keep the furniture placed steadily to prevent breakage or loosening.
- Please educate children to stay away from the glass sharp corners of the furniture.
- When opening and closing doors or drawers, handle them gently and check the screws regularly to tighten them.
- Use a soft dry cloth to dust, a slightly damp cloth to clean the surface, avoid abrasive cleaners.

Help Center

Treat your furniture with care and follow the maintenance guidelines. In return, your furniture will provide you with lasting comfort and support. For any additional inquiries or assistance, please do not hesitate to contact us



Inquiry



Assembly issue



Missing parts



Returns&Refunds

We look forward to seeing you again soon.