



Assembly Instructions
instructions de montage
Instrucciones de montaje


BERLIN
GARDENS

Mayhew Chat Swivel Rocker
Mayhew Chat Dining Swivel Rocker
Bascule pivotante pour chat Mayhew
Mayhew Chat Salle à manger pivotante à bascule
Mayhew Chat basculante giratoria
Mecedor giratorio Mayhew Chat Dining




Hardware Included
Matériel inclus
Herrajes incluidos


(214100) x4




(58200) x8




(114112) x4




(114134) x4



(2516114) x6




(2516134) x6



(61516) x6



(64516) x6




(72516) x6



(92350) x1



(95326) x1





(95321) x1




(9532) x1




Items Not Included
Articles non inclus
Artículos no incluidos







1




(A)
(C)




1a^(F)



2^(D)




3 (B)



4 (G) x3
(H) x1



Firmly Tighten All Bolts and Nuts
Serrez fermement tous les boulons et écrous
Apriete firmemente todos los pernos y tuercas



5


(H) x2
(I) x1

Firmly Tighten All Bolts and Nuts
Serrez fermement tous les boulons et écrous
Apriete firmemente todos los pernos y tuercas



6

(E)



(E)