


Instruction Manual



(Bottom Plate) 1 PC	(Front and Back Plate) 2PCS	(Left and Right Plate) 2PCS	(Metal Support Rod) 2PCS
(Back Plate) 3PCS			(Metal Extension Rod) 2PCS
A	B	C	D
(6x10 Screw with Cap) 58 PCS+4 PCS(Standby)	(Round 8 Screw Cap) 4 PCS	(Wheel) 4 PCS	(Wrench) 3 PCS

➤ Step1 Front Plate Installation

Fix ① and ② with five A's.

➤ Step2 Left Plate Installation

Fix ② and ③ with four A's, and fix ① and ③ with four A's.(The last screw does not need to be fixed for now.)

➤ Step3 Right Plate Installation

Fix ② and ④ with four A's, and fix ① and ④ with four A's.(The last screw does not need to be fixed for now.)

➤ Step4 Back Plate Installation

Fix ① and ⑤ with five A's.

➤ Step5 Metal Support Rod Installation


Fix ⑥, ③, and ⑤ with four A's, and fix ⑦, ④, and ⑤ with four A's.

➤ Step6 Wheel Installation (Choose whether to install as needed)

Tip the planting box over and fix C with four B's.

➤ Step7 Back Plate Installation

- 1) Fix ⑧ between the two metal support rods with six A's.
- 2) Place ⑨ between the two metal support rods, then place ⑪ and ⑫ respectively, fix them with six A's. And fix ⑧ and ⑨ with five A's.
- 3) Fix ⑩ in the same method.



Product Display