




ASSEMBLY INSTRUCTIONS

30 INCH BATH VANITY (COMBO)




Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment. Separate, identify and count all parts and hardware. Compare with the parts list to be sure all parts are present.
"DO NOT TIGHTEN SCREWS UNTIL COMPLETELY ASSEMBLED"


*** Use of power tool to assemble this product will invalidate any claim and damage this product making unsafe !!!**
*** Please assemble on a clean soft surface to avoid damage.**



Tools Required



(Not included)



(Not included)

IMPORTANT:

PLEASE READ INSTRUCTION BEFORE STARTING THE ASSEMBLY







Before Installation

Important – Please read these instructions fully before starting assembly


Thank you for purchasing this quality product. Be sure to check all packing materials carefully for small parts, which may have come loose inside the carton during shipment. Identify and count all items according to the PARTS LIST and/or HARDWARE LIST shown below. Check you have all the components and tools listed on the following pages.

- We recommend that you assemble this product with the assistance of another person; this will make the assembly easier, and will help eliminate damage to the product or injury to persons during assembly.
- Please do not over tighten screws or bolts until the assembly is completed.
- Keep children and animal away from the work area, small parts could choke if swallowed.
- Please put all parts on a non-abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.

Cam Lock Assembly Instructions















	Diagram A Insert Cam Bolt into hole as shown in diagram A.
	Diagram B Make sure not to insert the Cam Bolt: Too deep as shown in figure B as this will cause the Cam Lock to be misaligned and unable to interlock properly.
	Diagram C Also avoid inserting the Cam Bolt too close to the surface of the hole as shown in figure C, as this will cause the Cam Lock to be too loose, and not interlock properly.
	Connect the panels together.
	Insert the Cam Lock so the side opening fits over the head of the Cam Bolt.
	To tighten the Cam Lock, turn it clockwise on half a turn with a flat screwdriver. <i>*Do not use an automatic screwdriver as it may bend or break if too much power is imposed.</i>

Detail View - CABINET














Identifying the Hardware-Identify the hardware using the illustrations below.








Part List

1		2	
	Side Panel (L) - 1pc		Side Panel (R) - 1pc
3		4	
	Mid Panel - 1pc		Side Panel Top (L) - 1pc
5		6	
	Side Panel Top (R) - 1pc		Crossbar Top - 1pc
7		8	
	Panel Top Rear - 1pc		Flip Drawer - 1pc
9		10	
	Flip Drawer Face - 1pc		Frame Mid - 1pc
11		12	
	Rear Panel Bottom - 1pc		Bottom Panel - 1pc
13		14	
	Adjustable Shelf - 1pc		Door - 1pc

Part List


15		16	
Left Panel of Door - 1pc		Right Panel of Door - 1pc	
17		18	
Mid Panel of Door - 2pcs		Round Bar - 2pcs	
19		20	
Drawer Front Top - 1pc		Drawer Rear Top - 1pc	
21		22	
Drawer Side Top(L) - 1pc		Drawer Side Top(R) - 1pc	
23		24	
Drawer Bottom - 2pcs		Drawer Front Bottom - 1pc	
25		26	
Drawer Rear Bottom - 1pc		Drawer Side Bottom (L) - 1pc	
27		28	
Drawer Side Bottom (R) - 1pc		Sink - 1pc	

Hardware List


A  ø6x35mm	B  ø14.5x12mm	C  ø8xø4x25mm
Three in one bolts(35pcs)	Three in one lock(35pcs)	Round head screw(3pcs)
D  ø8xø4x32mm	E 	F  ø5/32"x20mm
Round head screw(24pcs)	Handle(5pcs)	Handle screw(1pc)
G  ø5/32"x25mm	H 	I 
Handle screw(4pcs)	Duo Forte (1pc)	Rotary Hinge(2pcs)
J  ø6xø3x12mm	K 	L  ø7xø3.5x15mm
Flat head screw(8pcs)	Damping hinge (2pcs)	Flat head screw(12pcs)
M 	N  ø8x30mm	O 
Laminate pad(4pcs)	Wood dowel(36pcs)	Anti fall hardware(1set)

STEP: 1


A




31PCS





Do Not Over Tighten




STEP: 2



B	C	N
		
5PCS	1PC	4PCS




STEP: 3




B	N
	
8PCS	6PCS


STEP: 4



B		N	
6PCS		6PCS	


STEP: 5




C		I		J	
2PCS		2PCS		4PCS	


STEP: 6

B		N	
6PCS		6PCS	




STEP: 7

H		J	
1PC		4PCS	





STEP: 8



B		N	
6PCS		6PCS	


STEP: 9




D		N	
8PCS		4PCS	

STEP: 10

A



4PCS



STEP: 11

B




4PCS

N




4PCS





STEP: 12

K		L	
2PCS		4PCS	





STEP: 13

E		F		G		L	
2PCS		1PC	1PC		8PCS		
(5/32" x 20mm)(5/32" x 25mm)							





Use the screws to adjust up or down

Use the screws to permanent





Use the screws to adjust left or right



Use the screws to adjust in or out




STEP: 14


M**4PCS**

STEP: 15

D**8PCS**


STEP: 16

E		G	
1PC		1PC	





STEP: 17

D	
8PCS	





STEP: 18

E		G	
2PCS		2PCS	




STEP: 19

O	
----------	---




STEP: 20

Install the sink (if applicable) on the cabinet with glue.
Let stand for 24 hours




*Silicone glue is not included in the package to comply with safety regulations in certain shipping conditions.

STEP: 21




HINGE ADJUSTMENTS




① Sideways / Tilt adjustment

Turn the screw
clockwise to move the door further away from
the side of the cabinet
anticlockwise to move the door closer to the
side of the cabinet



② ④ Height adjustment

While supporting the weight of the door, turn the
screws
clockwise to move the door up
anticlockwise to move the door down



③ Forward and back adjustment

If the gap between the back of the door and the
cabinet is too small, and the door may not close
fully. Turn the screw
clockwise to decrease the gap between the
door and the cabinet
anticlockwise to increase the gap between the
door and the cabinet

