




DINING TABLE

User Manual

INTRODUCTION

Thank you for choosing the dining table. Please read this user manual carefully and keep it for future reference. If you need any assistance, please contact us by email with your order number and details.


PACKAGE CONTENTS





- Dining table
- Pack of Accessories
- User Manual

PRODUCT CARE


- Please follow the instruction to assemble this item correctly.
- Don't make the screws be too loose or too tight.
- Please put the screws into the holes' position just as shown in the arrows of the image, and then clockwise rotate 90° or 180°
- The fittings pack contains small accessories that should be kept away from small children.

HARDWARE SUPPLIED

A M4  x1	B  x1	C M8*30mm  x16+1	D M4*16mm  x10+1	E  x4
F M7*50mm  x8+1	G  x2	H M6*25mm  x12+1		

PARTS LIST			
Unit: (mm)			
① 1100*550  x2	② 550*550  x1	③ 720*395  x2	④ 720*380  x2


PANEL LAYOUT



01

YOU WILL NEED


C x3



02

YOU WILL NEED



C x2



03

YOU WILL NEED

C x3





04

YOU WILL NEED

D x6


B x1




05

YOU WILL NEED

E x4



06




07

YOU WILL NEED

F x8

A x1


C x4



08

YOU WILL NEED

C x4




09


YOU WILL NEED


G x2


Dx4




10








Rotate
180°





GUARANTEE

Dining table offers a 90-days warranty that begins on the date of the original purchase and applies to problems caused by the manufacturer. For questions, assistance, or support, please contact the Customer Service by e-mail with your order number and details. We will send you further information about the solution.