


Replacement Part List



No.	Description	Qty.	No.	Description	Qty.
13	Valve core gland seat	2	25	Lock nut	2
12	Type a right handle	1	24	Flat washer	2
11	Type a left handle	1	23	Elliptic ring	1
10	M5x4 screw	2	22	M4 self tapping screw	4
9	Red button	1	21	Seat plate	1
8	Blue button	1	20	4 inch plastic body	1
7	Outlet water body	1	19	Panel	1
6	O-ring	2	18	O-ring	2
5	Card glue	1	17	Cross round head screw	2
4	Net nozzle shell	1	16	Plastic rod spool (blue)	1
3	Mesh bladder	1	15	Plastic rod spool (red)	1
2	Mesh liner flat pad	1	14	Outlet seat cover	1
1	Outlet elbow	1			