

HOLLS DINING CHAIR

Assembly instructions

PARTS LIST

NO.	DESCRIPTION	IMAGE	QTY
P1	Chair top		1
P2	Legs		4

HARDWARE LIST

NO.	DESCRIPTION	IMAGE	QTY
H1	Bolts Ø5/16 x 2-1/6"		8
H2	Lock Washers Ø5/16		8
H3	Flat Washers Ø5/16		8
H4	Allen Wrench		1

Important safety instructions:

- * Please read carefully all Instructions before assembling.
- * For your safety and ease, assembly by two or more adults is recommended.
- * Keep instructions for Future use.


Pre-assembly:

- * Do not discard any content until assembly completed to avoid accidentally discarding small parts or hardware.
- * Take out all parts and hardware from box.


NOTE: PO# is located underneath / at the back side of each item. Please be prepared to provide this # if necessary

CAUTION : Failure to follow these instructions may cause the bolts to misalign during assembly


Step 1: Turn over the chair and lay on protective carpet, using bolts (H1), lock washers (H2), flat washers (H3), connect legs(P2) to chair (P1). Tighten bolts (H1) with Allen Wrench (H4).



Step 2: Close the lower cover by pulling on the zipper.



Step 3: Place chair upright on a level surface. Assembly is complete



ASSEMBLY COMPLETED

ADDITIONAL NOTE ABOUT SAFETY: BOLTS MAY LOOSEN DURING NORMAL EVERYDAY USE. THEY SHOULD BE PERIODICALLY INSPECTED AND RE-TIGHTENED TO PREVENT DAMAGE OR INJURY. ALWAYS CHECK TO BE SURE THAT ALL HARDWARE IS KEPT TIGHTENED.