
ASSEMBLY INSTRUCTIONS:

- 1. CAREFULLY UNPACK AND PLACE ALL LAMP PARTS ON A FLAT SURFACE AND LINE THEM UP AS PER SKETCH.
- 2. INSERT HARP (B) INTO SADDLE AT THE TOP OF BODY (A).
- 3. PLACE SHADE (C) ONTO HARP (B) AND SECURE WITH FINIAL (D).
- 4. INSTALL THE LAMP BULB (E)(NOT INCLUDED) AND INSERT THE POLARIZED PLUG INTO AN OUTLET, TURN ON THE SWITCH AND ENJOY YOUR LAMP.

USE A 100W (MAXIMUM) IN CANDESCENT A TYPE BULB (NOT INCLUDED)



IMPORTANT SAFETY INSTRUCTIONS

THIS PORTABLE LAMP HAS A POLARIZED PLUG (ONE BLADE IS WIDER THAN THE OTHER) AS A SAFETY FEATURE TO REDUCE THE RISK OF ELECTRIC SHOCK, THIS PLUG WILL FIT IN A POLARIZED OUTLET ONLY ONE WAY. IF THE PLUG DOES NOT FIT FULLY IN THE OUTLET, REVERSE THE PLUG. IF IT STILL DOES NOT FIT, CONTACT A QUALIFIED ELECTRICIAN. NEVER USE WITH AN EXTENSION CORD UNLESS PLUG CAN BE FULLY AND EASILY INSERTED. DO NOT ATTEMPT TO ALTER THIS PLUG.

ATTENTION:

POUR PRÉ VE NIR LE S CHOCS É LE CT RIQUE S NE PAS UT ILISE R CE T TE FICHE POL ARISÉ E AVE C UN PROLONG AT E UR, UNE PRISE DE COUR ANT OU UNE AUT RE SORT IE DE COUR ANT, SAUF SI LE S LAME S PE UVE NT Ê T RE INSÉ RÉ E S A FOND SANS E N LAISSE R AU CUNE PART IE À DÉCOUVE RT.

- **** PLEASE INFORM YOUR DEALER IMMEDIATELY IN CASE OF ANY PARTS SHORTAGE.**
- ****** SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE.