
Instruction Manual




040FF
Version:2.0


Dear Customers,

Thank you for purchasing our product. Please read this instruction manual carefully after receiving this product. It will help you assemble this product quickly, safely and correctly. You can keep this manual for future reference.







Violent installation is prohibited

















Please call if you need help



Multi-person cooperation is recommended


1
11
4
3
8
1
3
6
8
13
8
1
10×16
12
9
8
3
9
5
10×16
16
14
3
18
2
7
17
18
15
17
18




Part list

1 3PCS 	2 1PC 	3 4PCS 
4 1PC 	5 1PC 	6 1PC 
7 1PC 	8 4PCS 	9 2PCS 
10 32PCS 	11 1PC 	12 1PC 
13 1PC 	14 1PC 	15 1PC 


Part list

16 1PC 	17 2PCS 	18 3PCS 

Hardware list

A	 M6*15mm	×20 +2	B	 M6*30mm	×3 +1	C	 M6*40mm	×6 +1
D	 M6*60mm	×29 +2	E	 M8*50mm	×16 +1	F	 4# Spanner	×1
G	 M8*80	×1	H	 M8 nut	×8 +1	I	 M8 washer	×41 +4
J		×2	K	 M6*80	×2	L	 M6*80	×1


1



Pay attention to the directon of the rivet nut when assembling.

I		M8 washer	8PCS
D		M6*60mm	8PCS


2



Pay attention to the rivet nut on the other side when assembling.

I		M8 washer	8PCS
D		M6*60mm	8PCS


3



When assembling No.8, pay attention to the round hole being directly above vertically.

A	⊣	M6*15mm	6PCS


4



When assembling No.8, pay attention to the round hole being directly above vertically.


A	⊣	M6*15mm	6PCS

5




H	●	M8 nut	8PCS
I	◎	M8 washer	16PCS
E	▬	M8*50mm	16PCS

6




7



13,14 Assembled as shown in Figure .


A	—	M6*15mm	8PCS
B	—	M6*30mm	3PCS

8




I	⌀	M8 washer	2PCS
D	—	M6*60mm	4PCS

9




I		M8 washer	6PCS
C		M6*40mm	6PCS

10




D		M6*60mm	4PCS

11




I		M8 washer	1PC
D		M6*60mm	3PCS


12



D		M6*60mm	2PCS

13







First, unscrew the assembled A,then lock J together as shown in the figure

J			2PCS


14






wall

15




16




Please lock the expansion screw onto the wall.

17



K		M6*80mm	2PCS

18



Assembled, tighten allthe screws