

When the remote control does not work, please follow the steps below to repair:

First, replace the remote control battery and make sure the battery is fully charged

Second, clearing code (The method is as follows)

Third, matching code (The method is as follows)

The method for clearing code:

Press the "ON" key 5 times in a row within 3 seconds of re-turning on the light, and the light flashes 6 times, that the code is cleared successfully.

The method for matching code:

Press and hold the "ON1" key within 3 seconds of turning on the light, the light flashes slowly for 3 times. then the code matching is successful.

When using the remote control for the first time,
please click this activation

