



STAINLESS STEEL PRESS PARTS LIST:



1. Lid
2. Shaft
3. Spring Screen
4. Plastic Screen
5. Mesh Screen
6. Metal Base
7. Handle
8. Beverage Container



STAINLESS STEEL PRESS

CARE & HANDLING RECOMMENDATIONS

STAINLESS STEEL PRESS

CARE AND HANDLING RECOMMENDATIONS

Capacity:

.35 Liter, .8 Liter and 1 Liter

Usage:

Wash before first use. This server is intended for hot or cold beverages. Do not use for any other purpose. Use caution when moving a full container. Use the handle to carry the server. Tip server to pour.

Cleaning:

This server construction assembly is dishwasher safe. For longevity of exterior body, we recommend hand washing.

- Do not use harsh cleansers, abrasives or solvents.
- Wipe exterior with a soft cloth and polish to maintain the polished exterior.
- Lids and screen sets must be hand washed.

Precautions:

- Do not overfill the dispenser.
- Keep away from children, especially when filled with hot beverages.
- Keep the dispenser away from heat sources, such as heaters and stoves.

Storage:

Store in a cool dry place.

Features:

- 18/8 stainless steel exterior and .6mm interior with double wall insulation.
- Coffee and tea maker is easy-to-use. Just fill coffee or tea, add hot water, let steep, and push the mesh filter assembly down.
- The mesh filter holds the grounds or leaves down to prevent the coffee/tea from becoming too strong.
- The grounds/leaves are prevented from floating to give you the best color, taste and flavor of the beverage.

How to Use:

1. Place the assembled press on a level surface. Hold the press firmly, grasp the knob on the lid and remove the mesh filter assembly.
2. Pre-heat the beverage holder with hot tap water. Let sit for 1-2 minutes and drain.
3. Fill beverage container with appropriate amount of medium to coarse ground coffee or tea leaves. Use 2-3 tsp. for 6-8 ounces of water, depending on preferred strength.
4. For best results pour 198° - 200° F hot water into the beverage container. Do not fill to the top, leave a small space. Replace the lid mesh filter assembly. Steep for 3-5 minutes depending on preferred strength.
5. After the coffee grounds/tea settles to the bottom, push mesh filter down slowly and serve in warmed cups. Care must be taken to plunge the mesh screen slowly to avoid splashing hot coffee/tea.

SERVICE IDEAS, INC.

2354 VENTURA DRIVE ~ WOODBURY, MN 55125

PHONE: 800-328-4493 ~ CS@SERVICEIDEAS.COM ~ WWW.SERVICEIDEAS.COM

10-38-100