


INSTRUCTION MANUAL



General Guidelines

- Please read the following instruction carefully and use the product accordingly.
- Please keep this manual and hand it over when you transfer the product.
- This summary may not include every detail of all variations and considered steps. Please contact us when further information and help are needed.

Notes

- This item is only intended to be used indoors. Personal injury and/or damage to product may occur if products are used outside of their intended purposes and/or if products have been changed/modified from their original design. The product must be assembled and used in accordance with the provisions of the manual. The seller does not assume any responsibility or liability with respect to any damage caused by incorrect assembly or improper use.
- It is recommended to mount the article by 2 adults. Please read assembly instructions before assembly and strictly adhere to each step outlined.
- If there is/are defective and/or missing part/s after unpacking, please cease assembly immediately and get in contact with us.
- Please assemble the item in spacious room and do not place the unwrapped product directly on the ground to avoid damage. It is recommended to wear gloves in the assembly to avoid scratch by the sharp edges.
- Please refer to the diagram during assembly. Align all the screws with the related pre-drilled holes first and later tighten the screws one by one after putting all the parts in the correct places.
- Please note that some types of parts have spare one.
- Periodically inspect screw tightness while the product is in use. If necessary, retighten to ensure structural integrity.
- Do not expose this product to direct sunlight or rain. Never touch with sharp objects or corrosive chemicals, which may spoil the surface of the item.
- For daily care, please clean with a damp cloth then immediately wipe dry.
- When you receive the product, please check all of the different accessories to ensure that all are present and undamaged. If there are any problems, contact us and provide photos so we can help you out.


Warnings

- It is not intended for use by children under 5 years of age. Children must be under adult supervision to use the product.
- It is forbidden for children to climb or play on the product to avoid serious body injury from toppling.
- During the assembly process, keep any small parts out of the reach of children; it may be fatal if swallowed or inhaled.
- To avoid the potential dangers of suffocation, please keep all parts and packaging.

NOTED:

- It is recommended that this item should be assembled by two adults.
- Assemble this item on a soft surface, such as cardboard or carpet, to protect finish.


HARDWARE




Ø6×35 mm



Ø15×9 mm



Ø8×30 mm



Ø4×35 mm

A x 68


B x 68

C x 16


D x 44



Ø3×12 mm



M6 × 60 mm





E x 48


F x 12

G x 12

H x 1



Ø 3.5 × 14 mm





I x 1

J x 12

K x 38

L x 2



M x 2


N x 12

O x 1


IMPORTANT:

1. Do not tighten bolts / screws completely until all bolts / screws are lined up and inserted into holes.
2. Do not over tighten screws and bolts to avoid stripping.
3. Please use hand tools to assemble this product. Do not use power tools.

PART LISTS




1 × 1




2 × 1




3 × 1




4 × 1




5 × 1



6 × 3




7 × 3




8 × 6


PART LISTS




9 × 6




10 × 6




11 × 6




12 × 2




13 × 2




14 × 2




15 × 2




16 × 4



17 × 4



18 × 1




19 × 6


How to install cam lock

Cam Screw


Clockwise rotate the CAM SCREW until the shoulder is against the surface of the board.



Hidden Cam





Insert the CAM SCREW into the HIDDEN CAM.
Clockwise rotate to tighten the HIDDEN CAM.





Step 1

When installing drawer slides, you need to detach the inner rail from the main body of the drawer slide. Locate the spring clip, and with a gentle press, you can easily remove the inner (movable) rail. As shown in the diagram.



N	x 12


Step 2




N1	x 6	E	x 12	A	x 8
		 Ø3 ×12 mm		 Ø6×35 mm	

Step 3


Flip the screws on the other side of the 180° lock



Step 4




Step 5




A	x 6
 Ø6×35 mm	

Step 6




B	x 8
 Ø15×9 mm	

Step 7




B	x 8
 Ø15×9 mm	

Step 8




B	x 8
 Ø15×9 mm	

Step 9




C	x 8	B	x 6
 Ø8×30 mm		 Ø15×9 mm	

Step 10




Step 11




C	x 8	D	x 6
 Ø8×30 mm		 Ø4×35 mm	

Step 12




G	x 12
 M6×60 mm	




Step 13



Step 14





Step 15




F	x 12	K	x 24	D	x 36	A	x 30
							
		Ø3.5×14mm		Ø4×35 mm		Ø6×35 mm	

Step 16




B	x 24
	
Ø15×9mm	

Step 17



Step 18 When the drawer is not in a level position, you can loosen the screws to make adjustments. After adjusting, tighten the screws again.



Step 19 Install an anti-tip strap

