

H3L

TABLE OF CONTENTS

01 Important Safety Instructions

01 Tools Needed

03 Parts List

05 Assembly

21 Warranty Information

Thank you so much for choosing our product. If you encounter any questions during use, feel free to contact us. We will try our best to solve it.

Customer Service Line: +1-888-292-2399

Customer Service Email: service7770@outlook.com

IMPORTANT SAFETY INSTRUCTIONS

- Check if all the parts are complete before installation.
- Read through the instructions before installing the cabinet.
- Keep the small parts away from children to avoid the risk of swallowing.

TOOLS NEEDED

Screws Driver -1PC




(Not included)

Hammer-1PC



(Not included)




General Assembly Guidelines


- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. The three main types of hardware used to assemble this product are: wood dowels, screws and bolts.
- IV. A Phillips head screwdriver is required for the assembly of this product.




V. Cam bolt and Cam lock Assembly instruction.




**Cam bolt
vertical installation**



**Cam bolt is
adjustable**




**Cam lock
the arrow is towards
the Cam bolt**




**180°
Ensure locking**


VI. Concealed hinges are three-way adjustable.



**Horizontal
by screw adjustment**





**In-and-Out
by loosening the hinge-arm
mounting screw or via cam
adjustment**
















**Vertical
Via slots in the mounting
plate or via cam adjustment**









VII. Two people are recommended for ease in the assembly of this product.






Packing List


1  x1	2  x1	3  x1	4  x1
5  x1	6  x1	7  x1	8  x3
9  x3	10  x3	11  x3	12  x3
13  x1	14  x1	15  x1	16  x1

17  x1		18  x1		19  555mm x1	
A M6x18  x6	B  x6	C  x24	D  x24	E M8x30  x4	
F M3.5x12  x48	G  x4	H M5x40  x4	I  x4	J M4x14  x18	
K M4x12  x4	L M4x40  x4	M  x3	N  x3	O  x6	
P  x4	Q M3x14  x16	R  x1	S  x2	T  x4	
U  x1	V  x1	W M3x10  x2	X  x2	Y  x2	
Z  x3					


Step 1




Step 2



Step 3



Q M3x14




x8

G




x4

Step 4




C




x20

Step 5



Q M3x14




x2

U



x1

Step 6




D



x20

Step 7






H M5x40




x4

Step 8




x4


Step 9




Step 10



Step 11




Step 12



Step 13

X3




F M3.5x12



x6

Step 14

X3




F M3.5x12




x6

Step 15



Put O parts firsty and
then assemble A
screws.



A M6x18





x6

O



x6

Step 16




F M3.5x12






x6

Step 17






Step 18




F	X	Y
		
M3.5x12		
x6	x2	x2

Step 19




X2

F M3.5x12




x8


Step 20



Step 21




Step 22



K	M4x12	S
		
x4		x2


Step 23




P

x4

Step 24




L M4x40




x4


Finish !!!



Before





After




Installtion tips: If the height of the door is inconsistent after installation, please Hinge adjustment.

Hinge adjustment


To facilitate the adjustment, install the E1 screw first, and then install the E2 screw.



Great bend





Middle curve



Straight arm

Hinge adjustment



a: To move doors up or down: loosen screws shown and move doors to suit. Once doors are aligned, re-tighten Screws F.



Hinge adjustment

b: To move doors in or out: loosen screw shown and move doors to suit.



Re-tighten screws



Hinge adjustment

c: To move doors left or right: loosen screw shown and move doors to suit.

Re-tighten screws



WARRANTY INFORMATION

- Do not expose the surfaces to direct sunlight or to extreme environmental conditions.
- Clean the surfaces preferable with a clean damp cloth, then dry with a clean towel.
- Do not use solvents or abrasive materials to clean the unit. If you decide to use a cleaning agent, test first on an area hidden from view.
- Replacement parts might be available to you at no charge, with an original proof of purchase and where a defect has arisen, wholly or substantially, as a result of faulty manufacturing, parts or workmanship during the Warranty Period.
- The warranty does not extend to regular wear and tear, nor the manufacturer assumes liability for damages or consequences due to accidents, incorrect assembly, negligence, improper use, modifications, or not heeding the above warnings.
- Thank you so much for your support! We hope you enjoy your purchase. If there is any damage or missing accessories, please feel free to contact us for free replacement or refund. You can quickly find us through
Customer Service Line: **+1-888-292-2399** .
Customer Service Email: **service7770@outlook.com** .
with your order number, we will try our best to solve this problem for you

Thank you !

