

Quick Start & Care Guide

Thank you for your purchase! Your new chair is thoughtfully designed to combine comfort, durability, and style. This guide will help you assemble, care for, and enjoy your chair safely and effectively.

Warranty Policy

Our Promise to You – 1-Year Limited Warranty

We stand by our quality and craftsmanship. Your chair is protected against manufacturing defects for one year from the purchase date.

What's Covered:

- ✓ Structural Defects – Issues with the wooden or iron frame.
- ✓ Hardware Failure – Problems with screws, bolts, or connectors under normal residential use.

What's Not Covered:

- ✗ Normal Wear & Tear – Fading, scratches, minor dents, or wrinkles from everyday use.
- ✗ Accidents & Spills – Damage caused by pets, liquids, or misuse.
- ✗ Improper Assembly – Damage due to incorrect setup or modifications.
- ✗ Commercial Use – Any use outside residential settings, such as restaurants, offices, or event rentals.

How to Claim Warranty Service:

- 1.Contact us via email at **xibanservice@hotmail.com**
- 2.Provide your order number and a clear photo of the issue.
- 3.Our support team will guide you through the replacement or repair process.

Assembly Guide & Installation Diagram


Before You Begin:

- 1.Check each part against the installation diagrams and confirm the numbers, names, and sizes match.
- 2.Clear a Space: Assemble on a soft surface, like a rug, to prevent scratches.

Installation Notes:


- 1.Use moderate torque with electric screwdrivers to avoid damage.
- 2.Insert all screws about 70% first to align the parts, then fully tighten them once everything is in place.

Assembly Diagram




A---U-shaped backrest*1


The back end has curvature



B---seat cushion*1



C---Connector*2




D---Foot pillar*4

E




20 × M6*20 Hex Screws

F



8 × $\varnothing 9$ * $\varnothing 19$ shim


G




4 × Decorative cover

Assembly Diagram

Step1: Fix the connector onto the seat cushion using
M6 * 20 hex screws




Step2:
Fix the backrest onto the connecting piece with
M6 * 20 hexagonal screws and cover it with a
decorative cover




Assembly Diagram

Step3: Fix the foot column with M6 * 20 hexagon socket screw



Assembly Diagram

Step4:
installation is complete



Care & Maintenance

Proper care ensures your chair stays beautiful and functional for years. Follow the steps below according to your chair's material.

General Guidelines:

1. Avoid Direct Sunlight – Prevents fading and material deterioration.
2. Keep Away from Heat Sources – Avoid radiators or fireplaces that can dry out or crack materials.
3. Tighten Periodically – Check screws and connectors every 3–6 months for stability.

Material-Specific Care:

Wooden Frame:

- Dust regularly with a soft, dry cloth.
- For stains, use a damp cloth with mild soap, then wipe dry immediately.

Iron Frame:

- Dust with a dry cloth.
- For cleaning, use a damp cloth with mild soap and wipe completely dry to prevent rust.

PU Leather:

- Wipe with a damp cloth.
- For tougher stains, use a PU leather cleaner. Avoid harsh chemicals.

Fabric Upholstery:

- Vacuum regularly with a soft brush.
- Blot spills immediately with a dry cloth.
- For stains, use a fabric upholstery cleaner following the instructions carefully.

Pro Tip: Rotate the chairs occasionally in your dining area to reduce uneven wear and fading.

Safety Guidelines

Your safety is our priority. Please follow these instructions carefully.

Weight Limit: Maximum 300 lbs / 136 kg.

No Standing: Never stand on the chair or use it as a step stool.

Sit Properly: Avoid sitting on the edges or leaning back excessively.

Protect Your Floors: Use felt pads under legs to prevent scratches on hardwood or tile floors.

Keep Parts Away from Children: Small hardware may pose a choking hazard.

Avoid Rough Use: Don't drag the chair or use it in ways that may compromise stability.

Quick Troubleshooting

Wobbly Chair: Check that all screws and bolts are fully tightened.

Uneven Legs: Ensure chair is on a flat surface and all feet pads are adjusted.

Stains: Clean promptly according to material instructions.