


ASSEMBLY INSTRUCTIONS

30INCH BATH VANITY COMBO

SKU:N725P467399





Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment. Separate, identify and count all parts and hardware.


Compare with the parts list to be sure all parts are present.

"DO NOT TIGHTEN SCREWS UNTIL COMPLETELY ASSEMBLED"


* Use of power tool to assemble this product will invalidate any claim and damage this product making unsafe!!!
* Please assemble on a clean soft surface to avoid damage.



+



Tools Required



(Not Included)



(Not Included)

IMPORTANT:
PLEASE READ INSTRUCTION BEFORE STARTING THE ASSEMBLY

PLEASE DO NOT RETURN TO STORE



**Please do not return this product to the retailer!!
We are able to assist you in ANY way**

If you find that you have any trouble with assembly or missing or damaged parts please contact the seller.

Before Installation









Important - Please read these instructions fully before starting assembly

Thank you for purchasing this quality product. Be sure to check all packing materials carefully for small parts, which may have come loose inside the carton during shipment. Identify and count all items according to the PARTS LIST and/or HARDWARE LIST shown below. Check you have all the components and tools listed on the following pages.


- We recommend that you assemble this product with the assistance of another person; this will make the assembly easier, and will help eliminate damage to the product or injury to persons during assembly.
- Please do not over tighten screws or bolts until the assembly is completed.
- Keep children and animal away from the work area, small parts could choke if swallowed.
- Please put all parts on a non-abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.

If you find that you have any trouble with assembly or missing or damaged parts please contact the seller.

Cam Lock Assembly Instructions













		Insert Cam Bolt into hole as shown in diagram A.	
		Make sure not to insert the Cam Bolt: Too deep as shown in figure B as this will cause the Cam Lock to be misaligned and unable to interlock properly.	
		Also avoid inserting the Cam Bolt too close to the surface of the hole as shown in figure C, as this will cause the Cam Lock to be too loose, and not interlock properly.	
			Connect the panels together.
			Insert the Cam Lock so the side opening fits over the head of the Cam Bolt.
			To tighten the Cam Lock, turn it clockwise on half a turn with a flat screwdriver. <i>*Do not use an automatic screwdriver as it may bend or break if too much power is imposed.</i>

Detail View - CABINET














Identifying the Hardware-Identify the hardware using the illustrations below.











Part List - N725P467399

1		2	
	Left Frame - 1pc		Right Frame - 1pc
3		4	
	Front Top Bar - 1pc		Front Middle Bar - 1pc
5		6	
	Back Top Bar - 1pc		Back Middle Bar - 1pc
7		8	
	Back Bottom Bar - 1pc		Middle Panel - 1pc
9		10	
	Bottom Panel - 1pc		Adjustable Shelf - 1pc
11		12	
	Flip Door - 1pc		Back Storage - 1pc





Part List - N725P467399

13		14	
	Door - 1pc		Left Panel - 1pc
15		16	
	Right Panel - 1pc		Middle Panel - 2pcs
17		18	
	Round Bar - 2pcs		Drawer Panel - 3pcs
19		20	
	Left Drawer Panel - 3pcs		Right Drawer Panel - 3pcs
21		22	
	Back Drawer Panel - 3pcs		Bottom Drawer Panel - 3pcs
23			
	Sink - 1pc		


Hardware List - N725P467399

A  Ø6x35mm Three in one bolts (31pcs)	B  Ø14.5x12mm Three in one lock (31pcs)	C  Ø8x30mm Wood dowel (33pcs)
D  Ø8xØ4x20mm Round head screw (4pcs)	E  Rotary Hinge (2pcs)	F  Support Arm (1pc)
G  Ø6xØ3x12mm Round head screw (8pcs)	H  Round head screw (5pcs)	I  Ø5/32"x32mm Handle screw (4pcs)
J  Ø5/32"x25mm Handle screw (1pc)	K  Ø6x30mm Wood dowel (12pcs)	L  Ø8xØ4x32mm Round head screw (24pcs)
M  Damping hinge (2pcs)	N  Ø7xØ3.5x15mm Flat head screw (12pcs)	O  Laminate pad (4pcs)
P  Anti fall hardware (2sets)		


STEP: 1



A






23PCS




STEP: 2


G	E	D	H	I
4PCS	2PCS	2PCS	1PC	1PC




STEP: 3




B	C
	
2PCS	2PCS




STEP: 4



B	C
	
3PCS	3PCS

STEP: 5




D



2PCS

STEP: 6



B




7PCS


C




5PCS

STEP: 7




B		C	
2PCS		3PCS	

STEP: 8




STEP: 9


B		C	
9PCS		8PCS	




STEP: 10




STEP: 11




STEP: 12



STEP: 13






A





8PCS

STEP: 14

B 	C 	M 	N 
8PCS	12PCS	2PCS	4PCS
		H 	J 
		1PC	1PC



STEP: 15



N





8PCS

N



Use the screws to adjust up or down

Use the screws to permanent




Use the screws to adjust left or right


Use the screws to adjust in or out




STEP: 16





O



4PCS




STEP: 17




STEP: 18

Install the sink on the cabinet with glue.
Let stand for 24 hours




*Silicone glue is not included in the package to comply with safety regulations in certain shipping conditions.

STEP: 19




HINGE ADJUSTMENTS




1 Sideways / Tilt adjustment

Turn the screw
clockwise to move the door further away from
the side of the cabinet
anticlockwise to move the door closer to the
side of the cabinet



2 4 Height adjustment

While supporting the weight of the door, turn the
screws
clockwise to move the door up
anticlockwise to move the door down



3 Forward and back adjustment

If the gap between the back of the door and the
cabinet is too small, and the door may not close
fully. Turn the screw
clockwise to decrease the gap between the
door and the cabinet
anticlockwise to increase the gap between the
door and the cabinet

