











Assembly Instructions


PALMER DINING TABLE 94"

<p>A</p>	<p>Table Top</p>		<p>X 1</p>	
<p>B</p>	<p>Table Leg or Base</p>		<p>X 2</p>	
<p>C</p>	<p>Bolt</p>		<p>X 8</p>	
<p>D</p>	<p>Washer</p>		<p>X 8</p>	
<p>E</p>	<p>Allen Key</p>		<p>X 1</p>	
<p>PALMER DINING TABLE 94"</p> 				<p>Before Starting:</p> <ol style="list-style-type: none"> 1. Choose a clean, level, spacious assembly area. Avoid hard surfaces that may damage the product. 2. Always read the instructions carefully before beginning assembly to ensure that you have all required contents. 3. To prevent choking hazards, keep the packaging material out of reach of small children 4. Do not over tighten the bolts as this may damage the thread. 5. Use only vendor supplied hardware to assemble. Using unauthorized hardware could jeopardize the structural integrity of the item. 6. The use of power tools to aid in assembly is not recommended. Power tools can damage hardware and split wood.
 <p>ASSEMBLY REQUIRES TWO PEOPLE</p>		 <p>20 MINUTE ASSEMBLY TIME</p>		 <p>KEEP INSTRUCTIONS FOR FUTURE USE</p>

Assembly Instructions


PALMER DINING TABLE 94"

1



Assemble the Base (B) to the Table Top (A) by placing each leg upright, lining up the threaded holes. Place one washer (D) over each bolt (C) and insert into threaded hole, tightening them with the Allen Key (E)

2



Carefully turn the table and stand on it's legs. Item is completed.