



ASSEMBLY INSTRUCTION



PLEASE DO NOT RETURN TO STORE




**Please do not return this product to the retailer!
We are able to assist you in ANY way!**





**If you find that you have any trouble with assembly or
missing or damaged parts please contact the seller.**


Please carefully review the following precautions before proceeding with the installation:












1. The installation process for this product is complex, and it is highly recommended to have at least two individuals working together during the installation.
2. Prior to each step, please refer to the screw hole positions to ensure that the board is aligned correctly according to the images provided in the instruction manual. This will help prevent any errors.
3. In case power tools are used for installation, it is important to tighten the screws intermittently rather than applying excessive force continuously. This precaution will help avoid potential cracks around the screw holes.
4. If you encounter any difficulties or issues during the assembly process, please don't hesitate to reach out to us via email or Amazon message. We assure you that we will address your concerns and provide a solution within 24 hours.


Thank you for your attention to these important instructions.







28 x2  29 x1 	30 x3 	31 x1  32 x1 
33 x1 	34 x1 	35 x1 
36 x1 	37 x1 	38 x1 
39 x1 	40 x1 	41 x1 
42 x2 	43 x2 	




Easy Installation:

-Can rotate the combination dial clockwise or counterclockwise


Set Your Own Password

-The password can be changed instantly
-No special tools required



1000 Combination Options

Change the password simply by pressing the button and setting the code in just a few seconds



Important Notes:

Password Setting

1. Password must be set when the lock is unlocked (default password is 0-0-0)
2. The reset position is located at the small hole on the lower edge of the outer ring; rotate the head until the internal button becomes visible (Can be used with accessory O)
3. Insert a small cylindrical rod into the button, press it down, and rotate the combination dial to align your desired numbers in the center
4. Release the button to complete the password setting








Locking & Unlocking

Rotate to lock the device




After locking, randomly turn one or all combination dials to secure the lock


To unlock, rotate the dials to match the preset password

Hardware


A	x90 +2(spare)	B	x90 +2(spare)	C	x73 +3(spare)	D	x34 +3(spare)	E	x7	F	x55 +3(spare)
											
Ø6x32mm				Ø6x30mm		Ø3.5x12mm		Ø4x25mm		Ø4x35mm	
G	x3	H1	x1	I	x17	J	x1	K	x1	L	x1
											
Ø4x40mm		H2	x1								
											
N	x1	M	x2	O	x1	P	x1	Q	x2	R	x38
											
								Ø6x20mm			
S	x2	CL	x3	CR	x3	DL	x3	DR	x3	CL	x1
											
Ø5x352mm		L350mm		L350mm		L350mm		L350mm		L300mm	
CR	x1	DL	x1	DR	x1						
											
L300mm		L300mm		L300mm							

STEP1



A	x10
	
Ø6x32mm	
B	x8
	



STEP2



F	x8
	
Ø4x35mm	


STEP3

DL=350mm
DR=350mm







DL	x2
	
L350mm	
DR	x2
	
L350mm	
D	x8
	
Ø3.5x12mm	


STEP4



N	x1
	

STEP5




A	x4
	
Ø6x32mm	



B	x4
	


S	x2
	
Ø5x352mm	



STEP6




DL=350mm
DR=350mm





DL	x1	F	x4
			
L350mm		Ø4x35mm	
DR	x1	D	x4
			
L350mm		Ø3.5x12mm	






STEP7

C	x2	B	x2
			
Ø6x30mm			
D	x4	DL	x1
			
Ø3.5x12mm		L300mm	
DR	x1		
		L300mm	




DL=300mm
DR=300mm



STEP8



CL=300mm
CR=300mm



CR	x1	CL	x1	D	x4
					
L300mm		L300mm		Ø3.5x12mm	


STEP9

CL=350mm
CR=350mm




A	x4	D	x12
Ø6x32mm		Ø3.5x12mm	
CR	x3	CL	x3
L350mm		L350mm	



STEP10



STEP11





STEP12





B	x4
	
C	x4
	
Ø6x30mm	

STEP13



B	x4
	
C	x4
	
Ø6x30mm	


STEP14



B	x2



C	x2
Ø6x30mm	

STEP15





E	x3
Ø4x25mm	
Q	x2
Ø6x20mm	

STEP16





A	x20
	
Ø6x32mm	
B	x3
	
C	x4
	
Ø6x30mm	

STEP17





B	x10
	
C	x11
	
Ø6x30mm	

STEP18





B	x4

STEP19




B	x8
C	x8
Ø6x30mm	

STEP20




B	x5
C	x4
Ø6x30mm	

STEP21





F	x4
Ø4x35mm	

STEP22




A	x26
	
Ø6x32mm	

STEP23




B	x8
	
F	x8
	
Ø4x35mm	


STEP24



STEP25





STEP26




F	x8
	
Ø4x35mm	
I	x17
	

STEP27




C	x4
	
Ø6x30mm	
A	x2
	
Ø6x32mm	
B	x3
	
E	x4
	
Ø4x25mm	


STEP28




B	x2
	
C	x4
	
Ø6x30mm	
F	x7
	
Ø4x35mm	





STEP29




B	x6
	
C	x2
	
Ø6x30mm	
D	x2
	
Ø3.5x12mm	
J	x1
	
K	x1
	

STEP30




B	x7
	
C	x4
	
Ø6x30mm	


STEP31




H1	x1
	
H2	x1
	

STEP32



G	x3
	
Ø4x40mm	
C	x4
	
Ø6x30mm	

STEP33



R	x38
	