




DINING CHAIR

L25




PARTS

#1 1pc




Seat

#2 1pc




Front leg

#3 1pc




Front leg

#4 1pc




Backrest

#5 1pc




HARDWARE

#A 4pc




M6*60mm

#B 4pc




M6*30mm

#C 4pc




M6*20mm

#D 8pc




M6

#E 1pc



ASSEMBLY INSTRUCTIONS


1



2

- Part (#2) ×1pc
- Part (#3) ×1pc
- Part (#5) ×1pc
- Haedware (#B) ×4pc
- Haedware (#D) ×4pc
- Haedware (#E) ×1pc

(#2) tripod down, (#3) tripod up, (#5) crossbar assembled with (#B)and (#D) hardware using (#E) wrench.



ASSEMBLY INSTRUCTIONS


3

Part (#4) ×1pc

Haedware (#C) ×4pc

Haedware (#E) ×1pc

(#4) Backrest (#C) screws assembled with (#E) wrench.



4


Part (#1) ×1pc

Haedware (#A) ×4pc


Haedware (#D) ×4pc

Haedware (#E) ×1pc

Align seat (#1) to the backrest , the nsecure by using bolts(#A) with hardwares(#E) with shim (#D).




ASSEMBLY INSTRUCTIONS



Install adiustable foot
nails at the potem

ASSEMBLY COMPLETED



Please ensure the
furniture rests on an even
and flat surface. If the
product wobbles or feels
loose, double-check all
bolts and/or screws are
properly tightened and
secured



Keep this handy!

Please retain this instucion
manual and any order-related
information for future reference.



Lift, don't rag!

To avoid damage to product
please always LIFT the product
when transporting or adjusting
the placement.