


Assembly & Installation Instructions

IMPORTANT SAFETY INSTRUCTIONS:

- **Warning:** If any special control devices are used with this fixture, follow the instructions carefully to assure full compliance with N.E.C. requirements. If there are any questions, please contact a qualified electric contractor.
- **Warning:** This product can expose you to chemicals including lead, which is known to the State of California, to cause cancer or birth defects or other reproductive harm. For more information. Please go to www.P65Warnings.ca.gov
- **Caution:** Electrician installation highly recommended. All glass material is fragile, use care when handling glass component(s) and or lamp(s).
Read instructions carefully and turn electricity off at the main circuit breaker panel before starting assembly

Illustration of assembly and wiring:

- I. F → E
II. D → F
III. C → F
IV. B → D
V. A → D



(Required Supply Circuit: 110V-120V, 60Hz. Bulb Type: 1*E26 * 6W Max)

Compatible Bulb Type (Included)

The mostly recommended bulb type is 6W LED Dimming bulb,3000K (TYPE A19 Bulb)

COMPONENTS INCLUDED IN THE PACKAGE

ASSEMBLY & INSTALLATION STEPS:

1. Open the box from top, take out all the components, parts bag and manual from the box carefully.
2. Check all the components against the parts list. Make sure get each parts on list.

Parts are NOT included for which is shown as 0 under QTY.

PARTS LIST		
Part Name	QTY	Code
Final	1 PC	A
Lampshade	1 PC	B
LED Bulb	1 PC	C
Harp	1 PC	D
Lamp body	1 PC	E
Wiring tube /Holder/socket	1 PC	F

3. Refer to the illustration and follow the steps as below, Before assembly.

- I Firstly,Fold the slightly overlong wire/cord and keep it tuck away in the wiring tube(F), then screw the wiring tube with internal threads into the top of the lamp body(E) with external threads.
- II Secondly,Pressing and Inserting the harp (D) into the lamp body holder (F).
- III Thirdly, screwing the bulb(C) onto the socket.(F)
- IV Finally, putting the lampshade (B) on the top of the harp(D) , and then screwing the final (A)into the top of the harp(D)
- V Tips: Pressing the top of harp(D)forward or backward to adjust the lampshade to a balanced position.

Instructions for use:

This table lamp is not only featured with USB and Type-C charging function, but also with a two prong outlet. Just lightly tap on any metal part of the lamp(Final included) to quickly change with three different brightness levels without delay.