


Assembly Manual



Pull Out Sleeper Chair Bed with Adjustable Backrest



CAUTION


THIS ASSEMBLY MANUAL CONTAINS IMPORTANT SAFETY INFORMATION.
PLEASE READ AND KEEP FOR FUTURE REFERENCE.

Count parts before assembling.


Ax1	Bx1	Cx1
		
Backrest	Seat	Pillow

ASSEMBLY INSTRUCTIONS


- 1 Open the carton, cut the straps at the bottom of the base.




- 2 Slide the Backrest (A) into the metallic quick connectors of the Seat (B). Push down the Backrest (A) firmly until each side is locked into place and an audible “click” is heard.




-
- 3** Zip up the Backrest (A) and the Seat (B) together.



- 4** Put the Pillow (C) on the Seat (B).




5 Assembly complete. Enjoy.




How to use the Sleeper Chair?


- 1 Hold the bottom of the Seat (B) and pull it forward.




- 2 Hold the belt in the middle and pull out the inner seat cushion.



-
- 3** After pulling out the seat cushion, press it down with both hands.
Warning: It is forbidden to put your hands under the seat.




- 4** Now the Sleeper Chair is ready for relax.




How to adjust the Backrest?

Lay down the backrest:

- 1) Push it forward all the way.
- 2) Pull it backward until you hear a click sound.




The backrest has 4 different positions: Push the backrest forward to get to different positions.




Retract the Sleeper Chair

- 1** Lift the seat cushion upward with both hands.



-
- 2** Hold the belt in the middle of the seat cushion, first pull it upward, then push it inward.



- 3** Now the Sleeper Chair is ready for relax.

