



















ASSEMBLY INSTRUCTION


QUEEN BED

A Headboard	B Footboard	C Extension Legs	D Side Rail - Front
			
1pc	1pc	2pcs	2pcs
E Side Rail - Rear	F Bar	G Slats - Front / Rear	H Slats - Center
			
2pcs	1pc	2pcs	2pcs
I Support Legs	J Bolts Ø1/4"x1/2"	K Bolts Ø1/4"x3/4"	L Bolts Ø1/4"x1-3/4"
			
6pcs	4pcs	18pcs	6pcs
M Bolts Ø1/4"x2"	N Hex Nut Ø1/4"x10mm	O Flat Washer Ø1/4"x16mm	P Allen Key M4
			
6pcs	4pcs	28pcs	1pc
Q Wrench Ø1/4"			
			
1pc			




This page lists all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.


- 1** Assemble Bar (F) to the Extension Legs (C) with Bolts (M), then fastened using Allen Key (P).




- 2** Assemble the Headboard (A) to the Extension Legs (C) with Bolts (J), then fastened using Allen Key (P).




3 Connect both Side Rail (D) & (E) using Bolts (K), Flat Washer (O) by Allen Key (P) as picture shown.




4 Attach the Side Rail (D) & (E) to Extension Legs (C) and Footboard (B) using Bolts (K) & (M), Flat Washer (O), Hex Nut (N) by Allen Key (P), Wrench(Q).



- 5** Attach the Support Legs (I) to Slats - Front / Rear (G) and Slats - Center (H) using Bolt (L), Flat Washer (O) by Allen Key (P) as picture shown.



- 6** Attach the pre-assembled Slats - Front / Rear (G) and Slats - Center (H) using Bolts (K), Flat Washer (O) by Allen Key (P) as picture shown.



Cleaning & Care

Treat surface with care. Surface is resistant to scratches but is not scratch resistant. Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.