


# Assembly Instructions

Caution : You must read this before you proceed

## RECLINER CHAIR (DOUBLE SEATS)









### Parts List

Label	Picture	Description	QTY (pc)
A	A line drawing of the backrest part of the chair, showing three horizontal sections and a curved top edge.	Backrest	1
B	A line drawing of the recliner base with the footrest extended. The footrest is shown in a reclined position, and a small circular logo is visible on the front of the base.	Recliner Base With Footrest	1

# Assembly Preparation


Before Beginning Assembly:



-  • Read instructions, cover to cover-
-  • Have 2 adults on hand for assembly-
-  • Do not assemble on flooring or carpet-
-  • Assemble on a clean non-marring surface (packing foam)-
-  • Save all packaging until finished-


# Assembly Steps

## Parts Introduction




This product has multiple parts and may require up to some 30 minutes to assemble. To give you an overview of the product parts, the above picture is to help you put the various parts into perspective. Please read through the instructions below to familiarise yourself with the parts and steps before assembly.

### Step 1



Take out the Backrest(A) from the Recliner Base with Footrest(B).

### Step 2




With assistance from your adult partner, hold up the fully assembled Backrest(A), standing behind the Recliner .

Insert the small metal arms on the sides of the Backrest(A) into the prefabricated slide lock gadget on the Recliner Base with Footrest(B) as shown above.

Firmly but gently, push the Backrest(A) downwards until the Backrest(A) is fully slotted and locked into position.


### Step 3



Smooth down the fabric flap on the Backrest(A).


Run your hands down both sides of the flap, from top to bottom, allowing the magic tape to adhere to the flap under the seat of the Recliner.

### Step 4



Make sure all parts are connected and securely locked into position.  
Your Recliner is ready for use.

### Step 5



**Disassembly Note:** open the flap on the Backrest(A), use a screwdriver (Don't use fingers) pressing outward on the metal ear on the preattached Metal Bracket on one side of the Recliner Base(B), with assistance of you adult partner to keep the Recliner Base(B) in place, pull out the Backrest(A) upward at the same time, repeat the same step for another side. Then the Backrest(A) can be taken out.

# User Instructions.

## Recliner

Please read the Instruction Manual below carefully before use.


Supervise children, when in use of this Recliner.



Always leave the chair in an upright and closed position after use.  
Keep hands and feet clear of the footrest mechanism and any gaps.  
Do not allow children to play on the chair.  
Do not lean to side to pick up anything while sitting on the chair.  
Do not sit on the arms.  
Do not stand up when the recliner open.  
Only the occupant should operate the chair.


To get into a open position-To push the Recliner Backrest

Sit into the seat.  
Open the trigger on the outside of right armrest,the Backrest will fall down and footrest will open when push the Recliner Backrest by your back.So do must put your feet on footrest well when you push down the Recliner Backrest.  
Use your body weight and push backwards into the seat into a fully reclined position.



To get out of Recliner-move Seatback into Upright Position

Tilt your body weight slightly forward and upwards.  
The seat back will come up to an upright position.  
Use your feet to push the footrest down.  
The Recliner will automatically lock when it is in the fully upright position.  
Where necessary,use your arms help lift/push yourself out of the seat



## Care & Maintenance



- Furniture may scratch floors. We recommend using furniture pads to protect your floors.



- Do not put hot items directly on furniture surface.



- Do not clean furniture with harsh cleansers or polish.



- Do not place furniture under direct sunlight.



- Do not place furniture near heating or cooling vents.



- Do not write on furniture without a padded barrier to protect the surface.



- Do not place furniture outside . For indoor use only.



- Not for commercial use. For residential use only.



- Stains may be removed with mild soap solution and damp cloth.



- Children should not climb or jump on the furniture.



- Dust and pick-up spills using a clean, non-colored, lint-free cloth.