


Owner Manual

Floor Lamp



Please pay attention to the warning signs
Read the instructions with caution before
operating and keep it properly

Warning

1. Before assembly, lay out all parts on a clean, flat surface and inspect each part for defects that may have occurred during shipping.
2. Inspect the wire insulation for any cuts, abrasions, or exposed copper that may have occurred during shipping. If there are any defects, DO NOT continue assembly. Please contact our customer service team immediately.
3. Consult a qualified electrician if you have any electrical questions.
4. To reduce the likelihood of tipping over, we recommend placing the lamp behind furniture and keeping children and pets away.
5. Never drape clothes over the lamp.
6. To prevent children from suffocating and choking, keep them away from packing materials.
7. Please keep this manual and pass it along when transferring the product.


Specifications

- Product Height: 63-75 in (160-190cm)
- Wire Length: 98.4 in (250cm)
- Input Voltage: 120Vac 60Hz
- Socket Type: Standard Medium E26
- Max.Load Power: LED Bulb 12W or Incandescent Bulb 60W
- Bulb: 9W, 2700K-6000K, 10%-100% DIM


One-Year Limited Warranty

We provide a one-year warranty for materials and workmanship from the date of purchase. Please note that the warranty does not cover damage caused by personal misuse or improper installation. Kindly attach your Order ID and Name so that our dedicated customer service team can assist you more efficiently.

Assembly Instructions



The remote control and the remote-controlled light bulb are matched one-to-one



Auto-off after 1 Hour: The bulb flashes once when pressed, indicating that the 1-hour timer mode has been activated. The timer will be canceled automatically if the lamp is turned on or off using the plug or remote control during the countdown.

Brightness: 10%-100%

Color Temperature: 2700-6500K

Memory Function: the floor lamp can remember the mode of the brightness you settled before closing.

If the remote control is unresponsive, please try re-pairing it:

Within 5 seconds of powering on, press any button to pair