


Floor Lamp

Assembly Instructions
Instrucciones De Asamblea
Instructions d'Assemblée



CAUTION

For indoor use only. Keep out of reach of children and animals. Place on flat surface and away from flammable materials. Never operate this appliance if it has a damaged cord, plug or cable. Keep cord away from heated and/or damp areas.

Use 120V~60Hz, 60 watt max. type A E26 bulb only.