


ASSEMBLY INSTRUCTIONS




TOOLS REQUIRED



Wrench

(Included)




Allen Wrench

(Included)



2 - People
Recommended

ASSEMBLY RATING



EASY —————> DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.



CHECK BEFORE STARTING

- | | |
|---|---|
| <input type="checkbox"/> Are you missing anything?
Double-check all parts, hardware and accessories listed on Page 6 are accounted for. | <input type="checkbox"/> Check out our Quick Tips!
We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then! |
| <input type="checkbox"/> Should we send any replacements?
Are there any irregularities or flaws in the parts? We can send replacements! | <input type="checkbox"/> Prep Time!
Please review the assembly instructions and all diagrams prior to assembling. Arrange parts as recommended on Page 7 and group identical hardware together to make assembling easier. |

PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.



Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.



Suitable Location

Assembling near the area of the intended location is highly recommended.



Sufficient Space

Make sure you have enough space to move around during the assembly.



Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent scratches.



Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

ASSEMBLY AND CARE ADVICE



**FAILURE TO FOLLOW THE GUIDELINES BELOW MAY
RESULT IN INJURY AND/OR PROPERTY DAMAGE.**



Position each part correctly
and insert screws or bolts into
their respective holes.



Turn clockwise to tighten and
only tighten when step is
completed or when instructed
to do so.



Save the instructions and store
any supplied tools for later
maintenance.

Use the appropriate hand tools
or power tools for assembly.
Select steps, such as tightening
screws and/or bolts, may require
hand tools to avoid causing
damage during assembly.




After two weeks, check and
tighten any loose hardware and
repeat again every six months
thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

SOFA TABLE




- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.




PARTS

#1 1pc




Top Frame

#2 1pc




Middle Frame

#3 1pc



Bottom Frame


#4 6pcs



L: 275mm

Upper Leg

#5 10pcs



L: 457mm

Middle Leg


#6 4pcs



L: 40mm


Bottom Leg

#7 1pc



Large Glass

#8 1pc



Small Glass


#9 1pc



Mirror


HARDWARE

#A 10pcs




Full-Thread Bolt
1/4" * 38mm

#B 6pcs



Full-Thread Bolt
1/4" * 70mm

#C 6pcs



Bolt 1/4" * 45mm

#D 4pcs



Bolt 1/4" * 70mm

#E 6pcs



Nut

#F 4pcs



Plug

#G 4pcs




Sucker

#H 6pcs



Rubber Mat

#I 2pcs



Safety Strap

#J 2pcs



Plastic Bracket

#K 4pcs



Anchor

#L 4pcs




Screw

#M 1pc



Wrench

#N 1pc




Allen Wrench

ASSEMBLY INSTRUCTIONS


1

Part **#1** x1pc
 Part **#4** x6pcs
 Hardware **#A** x6pcs



2

Part **#2** x1pc
 Part **#5** x6pcs
 Hardware **#B** x6pcs
 Hardware **#E** x6pcs




ASSEMBLY INSTRUCTIONS

3

Part #5 x4pcs

Hardware #A x4pcs




4

Part #3 x1pc

Part #6 x4pcs

Hardware #C x6pcs


Hardware #D x4pcs



ASSEMBLY INSTRUCTIONS

5

Hardware  #F x4pcs




6

Part  #7 x1pc


Part  #8 x1pc

Part  #9 x1pc

Hardware  #G x4pcs

Hardware  #H x6pcs

Attach rubber mats (#H) onto middle frame tabs, then attach suckers (#G) onto top frame hole before putting on glasses (#7,8).



ASSEMBLY INSTRUCTIONS


7

Hardware#1 x2pcs

Hardware #J x2pcs

Hardware #K x4pcs

Hardware#L x4pcs



ASSEMBLY COMPLETED



Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.



Keep this handy!

Please retain this instruction manual and any order-related information for future reference.



Lift, don't drag!

To avoid damage to product
please always LIFT the product
when transporting or adjusting
the placement.


ASSEMBLY INSTRUCTIONS

Wall Mounting and Fixing



EXPANSION WALL ANCHOR

Our provided expansion wall anchors are only suitable for masonry walls, such as drywall, plaster or concrete, and are best for holding lightweight items or for anti-tip prevention. If you are unsure of the correct wall anchor to use with the product, please request professional guidance. Liability for product damage or failure due to using the incorrect anchors will fall on the installer.




CHECK BEFORE PROCEEDING


Prior to drilling or hammering, please check for wires or pipes. We recommend using a stud finder to locate a stud, which will offer more appropriate resistance and hold more weight.

QUICK TIPS


1. If unsure of the proper size, always choose a larger screw and wall anchor.




2. Match the drill bit to the wall anchor and hole size.



3. Only drill horizontally. Do not force the drill or enlarge the hole for the wall anchor.



4. Take extra care when drilling into high walls or ceramic tiles. Wall anchors should be a tight fit for the hole. Never use wall anchors in ceilings.



MAINTENANCE



We recommend a yearly check to see if the wall anchor or screw has loosened. If so, please remove the existing wall anchor and screw, and use a new anchor.