Champagne Glitter Reindeer



Illustrated assembly guide

MODEL KS6654

Finished dimensions
34.65 in L x 11.81 in W x 71.65 in H

Keep the power disconnected while joining the frame and light connections. Use the supplied power source for your item.

Before you begin

Arrange the components on a clean surface. Body, four legs, center braces, head, antlers, tail, bow, LED cords, adaptor, zip ties and stakes.



Have scissors ready when zip ties are used. Cut only excess tie ends; keep scissors clear of the light wires.

Assembly sequence

Follow the numbered steps. Check each frame and cord connection before applying power.

1 Attach the four legs



Match each leg to its body position using the LED cord location. Fit the legs and secure each one tightly with zip ties.

2 Add the center braces



Stand the reindeer upright and attach the center brace connection to the front and back legs.

3 Fit the tail and antlers



Attach the tail at the rear. Fit the antlers to their connection points on the head.

4 Connect the head lights



Lay the reindeer on its side and join the LED light connection from the head to the body.

Assembly sequence

Follow the numbered steps. Check each frame and cord connection before applying power.

5 Secure the neck



Hook the rear of the neck onto the body, then zip-tie the front of the neck to the body frame.

6 Finish and position



Hook the ribbon bow onto the neck or the preferred frame area. Use ground stakes outdoors if needed, check connections, and connect the adaptor to test the lights.

Warranty?
Troubleshooting?

Scan the QR code for instructions, support, & registration.

XProductSupport.com/product/KS6654

Instructions, support & warranty

Scan the mini card or click below to:

Watch the instructional video
Create a support ticket
Register your item for warranty

XProductSupport.com/product/KS6654