

USER MANUAL

Applicable for Infrared Saunas



INDOOR SAUNA HY-1

Installation Procedure

Fasten by buckle



1, Floor Panel



2, Rear Panel



3, Left Panel



4, Right Panel



5, Bench Support



Connect the wires to sockets



6, Bench Panel



7, Front Panel
(Install the handle)



8, Top Panel
(Fix the screws on roof)



Connect Wires on roof



Fix the dust-proof cover


Accessories



Oxygen Ionizer


Press the button to switch on/off.
When switch on, it releases negative ion to fresh the air inside the cabin.

Operation Instructions of Control Panel



Power Button (On/Off)

This button turns the sauna on or off.





Light Button (On/Off)

This button turns the reading light on or off.




Temperature Setting

Press  or  button to increase or decrease the sauna temperature. The heaters will turn off when the sauna reaches its desired temperature.

Temperature setting ranges from 64 to 149°F. Press Light Button 3 seconds to swift °F to °C.



Timer

Press  or  button to increase or decrease the sauna timer. It will count down until 00 and shut down the heaters.

Tips: Time setting ranges from 1 to 99 minutes.

Blue-tooth function: Source SAUNA BT on your mobile phone or other devices with Blue-tooth, connect with it when the sauna turns on, then you can play music etc. via blue-tooth. To adjust volume, change playing turns, pause or stop via your mobile phone.

Trouble shooting

Error code E0: The temperature sensor doesn't connect well, connect it again.

Error code E1: There is a short circuit, replace a new temperature sensor or circuit board.

For more troubleshooting advice or to report a problem, please contact with your supplier.