
ASSEMBLY INSTRUCTIONS



SAFET YTIPS:

Static charge may cause dust on

foam-clean with a dry or damp cloth.Small foam strands may be present-handle gently and dispose of properly.Do not burn or incinerate. Check localrecycling guideline.

Have an assembly question or need a replacement part?

Please contact with our customer service.

Warnings

Important reminder:

⚠ Please sort and check all accessories before assembly.

⚠ Place the product on an empty cardboard box or on carpet to prevent scratches.

⚠ Please use proper tools for assembly.Using an electric screwdriver can accelerate the assemoly speed, but please do not overtighten the screws.


⚠ Please follow the assembly steps and do not skip any of them.


⚠ If possible, please find a partner to help you with assembly, which can accelerate assembly.

⚠ Keep all small parts of this product away from children. They may cause serious injury.

⚠ We hope you can retighten the screws 2 weeks after assembly, and check the tightening procedure of the screws every 3 months.


If you meet any difficulty, our friendly customer team are always ready to help you.






Warning: 0verturning the product can cause serious crushing injuries. We have a wall connection device attached, please use it to hold the furniture following assembly instructions
Do not change the structure of this product inway. Our products have been testedand meetanyal 1sales specific security measures. We won'tbe responsible for any modifications,whichmay cause significant security risks


Explosion Diagram




Parts List




1 X1




2 X1




3 X1




4 X1




5 X1




6 X2




7 X1




8 X1




9 X1




10 X1




11 X1




12 X1




13 X1




14 X1




15 X1




16 X1




17 X1




18 X1



19 X1




20 X2




21 X2


Parts List




22 X1




23 X1




24 X1




25 X1



26 X1























27 X1





28 X1

Hardware List


No.	Code	Diagram	Description	Quantity	Spare
1	**A**		Ø6 x 33.5 mm	62	2
2	**B**		Ø15 x 9 mm	62	2
3	**C**		Ø6 x 30 mm	34	2
4	**D**		Ø5 x 38 mm	14	2
5	**E**		Ø3.5 x 14 mm	10	2
6	**F**			2	
7	**G**			2	
8	**H**			4	
9	**J**		M4 x 20 mm	8	2
10	**K**			2	
11	**L**		Ø4 x 12 mm	2	
12	**M**		Ø4 x 35 mm	2	
13	**N**		8 x 30 mm	2	
14	**P**		Ø3 x 12 mm	65	2
15	**Y**		Ø3 x 12 mm	4	
16	**Z**			2	
17	**S**			1	
18	**T**			1	
19	**U**		Ø3.5 x 12 mm	48	2
20	**V**		Ø26mm	8	

THE SPARE BAG INCLUED EXTRA HARDWARE FOR DAMAGED OR MISSING SMALL HARDWARE WHILE YOU ARE ASSEMBLING

Hardware List

No.	Code	Diagram	Description	Quantity	Spare
21	**W**		Ø25 mm	62	2
22	**R**		45*11.5*9	1	


Spare parts are packed together in one package.





THE SPARE BAG INCLUED EXTRA HARDWARE FOR DAMAGED OR MISSING SMALL HARDWARE WHILE YOU ARE ASSEMBLING

Assemble

Step 1











Assemble

Step 2

			
B	12PCS	C	6PCS













Assemble


Step 3

						
A	6PCS	B	6PCS	C	3PCS	















Assemble


Step 4


								
F	2PCS	E	4PCS	D	6PCS	C	3PCS	


A	10PCS

















Assemble

Step 5

						
B	4PCS	C	2PCS	A	4PCS	











Assemble

Step 6













Assemble


Step 7





Assemble

Step 8

						
D	4PCS	C	2PCS	A	8PCS	









Assemble

Step 9




B	22PCS	C	10PCS




Assemble

Step 10


B	10PCS	C	5PCS	







Assemble

Step 11

		
P	33PCS	







Assemble

Step 12




P	32PCS








Assemble

Step 13

							
E	2PCS	R	1PC	T	1PC	Y	2PCS














Assemble

Step 14






								
G	2PCS	Y	2PCS	U	16PCS	V	8PCS	








Assemble


Step 15

							
H	4PCS	J	8PCS	S	1PC	E	4PCS













Assemble

Step 16

	
U	32PCS










Assemble

Step 17









Assemble


Step 18







Assemble

Step 19








x2





Assemble


Step 20

	
B	4PCS










Assemble



Step 21




Slowly push the box into the furniture cabinet.

Assemble


Step 22

				
L	2PCS	K	2PCS	



Assemble


Step 23





⚠ Warning: If you overturn the furniture, it may cause serious or fatal crushing injuries.


We have a wall connection device attached, please use it to hold the furniture following these instructions.


1. Mark the corresponding hole positions where you want to place the furniture;
2. Use a impact drill to drill holes and pay attention to avoid wires and water pipes;
3. Knock the expansion pipes into the wall holes;
4. Place the furniture in the corresponding position and tighten the wall connection device with screws.













InstallationCompleted

Assemble


Step 24







Assemble

Step 25




YOU WILL USE HINGE ADJUSTMENT INSTRUCTION ON THIS PAGE FOR THE NEXT STEP.







If you find a large gap above or bellow the door.

To adjust the vertical height.
Loosen the four screws "A" on both hinges.
Two of them are usually in slotted holes which allows you to adjust up or down by a few mm.
Then tighten back up.









If you find the door is too protruding or too inside.

To adjust depth.
Loosen screw "B" on both hinges and move the door to suit.If the door doesn't move,turn screw "C" on both hinges 1-2 turns and try again.Finally,tighten both screw"B"and reset both screw"C".





If you notice large gaps between or beside the doors,or if two doors in middle get stuck together,don' t worry—this is not a product defect.

To adjust side ways.
Turn screw"C"clockwise or counterclockwise on both hinges until the door is in the desired position.