


HAPPINESS HAPPINESS INSTALLATION



- If you have any questions with the product, please contact us by:
- **Email: customerservice@zoy-living.com**
(we will reply to you within 24 hours)

Assembly Instructions




RW042AF61N

This product comes in One package. Carefully remove all of components from the packaging and set aside for assembly.

CAUTION


DO NOT use any sharp objects to open plastic-wrapped components as this may result in damage to the product or components.

Package Contents

		
Part A*1 Seat Body	Part B*1 Left Backrest	Part C*1 Right Backrest




STEP 1

Attach **Back(B&C)** to **Seat (A)** by aligning the metal grooves as shown. Ensure the **Back(B&C)** slides down fully over the brackets on the **Seat (A)**.




FINALSTEP

Connect the parts of the sectional assembly by means of the metal slots at the bottom.



SIZE DIMENSIONS



Warnings

1. Please check if the components of the chair are all included and can be used normally.
2. Assemble all components according to the instruction correctly before you connect the chair to the power.
3. Please DO NOT sit on the armrests or footrest to eliminate the risk of tipping over.
4. If the chair is damaged or doesn't match the website description, please send clear pictures of the product and label of the carton to our service team for further help.
5. If the recliner doesn't work, you may try the following measures for self-checking firstly:
 - a) Check if all the cables are connected;
 - b) Check if the light of transformer is on.If the chair still doesn't work, please feed the information back to our customer service in time and we'll help you solve the matter as soon as possible.
6. If you have any questions with the product, please contact us by:

Email: customerservice@zoy-living.com (we will reply to you within 24 hours)

