


Converting the Echo

Converting to Sofa


Standing at the side of the unit (from bed position), lift backrest to the desired position and secure in place by releasing to the sound of a click.

IMPORTANT: During conversion, ensure lifting is done from the back of backrest.



Converting to Lounger


In bed position, lift backrest upwards with each click sound until a desired lounge position is reached.




Converting to Bed

From sofa or lounge position, lift backrest all the way upwards until the last click is heard which unlocks the mechanism and carefully return to a flat position.


IMPORTANT: Ensure that the support legs are extended out (behind the backrest) when using it as a bed.



Echo




Parts and Hardware



Bolt




Allen Key



Leg




Center Support Leg




Sofa Body

Assembling the Echo

- 1** Carefully unpack and place sofa body unit upright on a clean flat surface to show the base as shown.
- 2** Align and secure both legs with two short bolts at each end using the Allen key.



- 3** Secure center support leg by screwing into metal plate on center of the base by hand and avoid overtightening.



- 4** Finally, carefully lift and turn assembled unit onto its legs. Two persons required to avoid personal injury.