


Website : www.x-cosrack.com

E-mail : info@x-cosrack.com





Facebook: www.facebook.com/cosrackofficial/

Assembly Instructions





CAUTION:When tightening the screws ,tighten sequentially.
Do not tighten any screws fully and then towards the next one.
When every part is OK,then tighten all the screws.



Parts Included







1. Connect the three iron frames P to the wooden board G with screws ③.




2. Connect board H to board K with screw ①.




3. Connect A and B with screws ③, then get AB; Connect C and D with screws ③, then get CD; Connect E and F with screws ③, then get EF. The adjustable feet ⑤ are installed at the bottom.



4. The iron frames CD and EF are connected to the 3 wooden boards J with screws ①.





5. Connect the assembled wooden board H to the iron frame AB/CD with screws ①.





Note that AB and CD have small holes on the same side.


6. Connect the assembled wooden board G with the iron frame AB/CD with screws ②.
Connect the two wooden boards L to the iron frame AB/CD with screws ①.




7. Fix the two mesh board O on the down part in front of the rack with screws ④.



8. Fix the two mesh boards M onto the wooden board J with screws ④.



9. Fix the mesh board N at the top part behind the shelf with screws ④.



Thank you for choosing this product!