



SKU:SF001014BK





Trouble Shooting

Missing/Damaged pieces/
Wrong size and installation issues



Contact us with your problem,pic,
number and qty to the "Contact seller"
button in the detail page of your order







Respond with 24 hours to solve issue

Before You Start


1. Read through each step carefully and follow the proper order
2. Separate and count all your parts and hardware
3. Give yourself enough room for the assembly process
4. Caution: If using a power drill or power screwdriver for screwing, please be aware to slow down and stop when screw is tight. Failure to do so may result in stripping the screw

Cam Lock Fastening System

This Cam Lock Fastening System will be used throughout the assembly process




Parts List




1

1PC




2

1PC




3

1PC




4

1PC




5

1PC




6

1PC




7

1PC




8

1PC



9




1PC







10

1PC

Hardware List

		 ø15		 Ø8*30mm		 Ø4*40mm	
A	20PCS	B	20PCS	C	10PCS	D	3PCS
Ø3.5x14mm 						M4x18mm 	
E	24PCS	F	2PCS	G	4PCS	H	4PCS
 LED		 Ø10*70					
I	1PC	J	6PC				

STEP 1



STEP 2



ø15

B	2PCS
---	------




Ø8*30mm

C	2PCS
---	------



Ø4*40mm

D	3PCS
---	------



STEP 3




ø15

B	9PCS
---	------



Ø8*30mm

C	4PCS
---	------



STEP 4




Ø15

B	9PCS
---	------



Ø8*30mm

C	4PCS
---	------




STEP 4




LED


I	1PC
---	-----



STEP 5




STEP 6



Important

2 people required
2 personnes requises
2 personas requeridas



STEP 7

Ø3.5x14mm





E

8PCS



G

4PCS



STEP 8



F



2PCS

M4x18mm





H


4PCS



STEP 9






STEP 10



Important



2 people required
2 personnes requises
2 personas requeridas

Door Hinge Adjustment Instructions





To adjust the height.

Loosen the two screws 'A' on the hinges, typically found in slotted holes, to allow for vertical adjustment by a few millimeters. After making the adjustment, tighten the screws back in place.



To adjust the depth.

Loosen screw 'B' and adjust the door. If the door cannot be adjusted, please loosen screw 'C' and try again. Once the adjustment is made, tighten both screws 'B' and 'C'.



To adjust the side ways.

Turn screw 'C' on both hinges of each door.