
CHAISE & A PIECE OF GLASS



CARE & MAINTENANCE

- Inspect and tighten all bolts and fasteners on a regular basis to ensure the proper performance and safety of your product.
- Wash all frames with a solution of mild soap and water. Rinse with clean water and dry with a soft, absorbent cloth towel.
- Always place your patio furniture away from fire, extreme heat, freezing conditions, and inclement weather such as rain, hail, sleet, snow or wind.

WARRANTY GUIDELINES


- This warranty runs for one year from the date your product is installed.
- If this product or any associated parts are found to be defective or missing at the time of receipt,
 Lausaint Home will repair or replace, at its option, the defective parts at no charge to the original purchaser.
- Continuous free technical support is provided, including online diagnosis and troubleshooting
 of users' problems, and coming up with solutions in time.
 In order to process your claim, please offer your order information along with AT LEAST 2
 photos of the issue/damaged parts.

What is not covered by this limited warranty?

- Consumer misuse is not covered.
- Failure to follow recommended care will void the product warranty.
- Manufacturing defects only.
- · Normal wear and tear not covered.
- Third-party labor or installation fees.


Component List - Chaise

DO NOT FULLY TIGHTEN ALL SCREWS UNTIL ASSEMBLY IS COMPLETED.






Parts





Chaise Installation









M6 X 40mm CC(x2) \bigcirc KK(x2)








1.4



DD



1.5




C(x4)



M6 X 35mm BB(x8)



DD








Н







DD









2.1



