


Assembly Instructions
COUNTER SIDE CHAIR


- Caution: Please read instructions thoroughly before unpacking assembly parts. Sharp, exposed staple tips can cause injury, therefore, for your protection, please remove any exposed staples used in packing.
1. We recommend that you should assemble this product with the assistance of another person; this will make assembly easier, and will help to eliminate damage to the product or injury to persons during assembly.
 2. Be sure to check all packing materials carefully for small parts that may have come loose inside the carton during shipment.
 3. Please do not over tighten screws or bolts.
 4. Please put all parts on a non-abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.

PART LIST FOR COUNTER SIDE CHAIR			HARDWARE LIST PACKED INSIDE BOX		
No.	PART DESC	Q'TY	No.	HARDWARE DESC	Q'TY
A	COUNTER SIDE CHA R BACK FRAME	1	1	 ALLEN BOLT (1/4" x 40mm)	2
B	COUNTER SIDE CHA R SEAT FRAME WITH CUSHION	1	2	 ALLEN BOLT (1/4" x 75mm)	4
C	COUNTER SIDE CHA R FRONT LEG L / R	2	3	 ALLEN BOLT (1/4" x 60mm)	4
D	COUNTER SIDE CHA R S DE STRETCHER L / R	2	4	 SPRING WASHER (1/4")	10
E	COUNTER SIDE CHA R FRONT STRETCHER	1	5	 FLAT WASHER (1/4")	10
			6	 SCREWS (M4x38mm)	6
			7	 ALLEN KEY M4	1

STEP:1



STEP:2



COMPLETED

