

SAFETY INFORMATION

Released Date: 2022-06-13

Please read and understand this entire manual before attempting to assemble, install or operate the product.


WARNING

- RISK OF ELECTRIC SHOCK - Before beginning installation, turn off electricity at the circuit breaker box or the main fuse box.
- RISK OF FIRE - Use bulbs specified by the markings and/or labels on the fixture.

CAUTION

- For your safety, read instructions completely before beginning installation.
- If in doubt about electrical installation, consult a licensed electrician.
- Turn off electricity to fixture before replacing the bulb(s).

TOOLS REQUIRED



CARE AND MAINTENANCE


- Wipe clean using soft, dry cloth or static duster. Always avoid using harsh chemicals and abrasives to clean fixture as they may damage the finish.

If you need further assistance call Quoizel Customer Care at 1-800-645-3184 (9:00am - 5:00pm EST), or visit us on-line at www.quoizel.com.


PACKAGE CONTENTS



A Fixture Loop
x 1




Fixture Body
x 1 **B**



C Glass Shade
x 4

Glass panels may be different than pictured based on which item was purchased.

MOUNTING HARDWARE




AA Crossbar Assembly
x 1



BB Wire Connector
x 3



CC Outlet Box Screw
x 2



DD Ceiling Canopy
x 1




EE Quick Link
x 2



FF Fixture Chain
x 1

1

Install Glass Panels




Slot

Tab

Glass panels may be different than pictured based on which item was purchased.


2

Install Fixture Loop



3

Install Crossbar Assembly




Outlet Box

Canopy Lock Ring

4


Install Fixture Chain



OPTIONAL: Adjust Chain as desired, using pliers and soft cloth (neither included).

Suggested chain length for Ceiling height:

Ceiling height	Chain links	Quick links
8 feet	4	2
9 feet	14	2
10 feet	24	2



* Ceiling Canopy shape is varies depends on item purchased.

Ceiling Canopy

Canopy Lock Ring

5

Pull Supply Wires

Pull the supply wires with ground wire through the chain alternate links.

6

Wiring

White wire from supply Ribbed side of wire from fixture identified with the label "N"

Black (or red) wire from supply Smooth side of wire from fixture identified with the label "L"

Ground wire from supply Ground wire from fixture identified with the label "G"

Green ground wire

7

Install Ceiling Canopy

* Ceiling Canopy shape is varies depends on item purchased.

8

Install Bulb

Install the correct bulb referring to fixture markings and/or labels for maximum wattage.

Recommended Bulb Type (not included):

BULB BASE TYPE Medium (E26)	BULB TYPE TYPE A

Your installation is now complete! Restore electricity and save this sheet for future reference.