

Wicker Chair

Brown
Black
Tan
Gray



**SAVE THESE
INSTRUCTIONS FOR
FUTURE REFERENCE.**



**ATTACH YOUR
RECEIPT HERE**

Keep a copy of your proof of purchase or order confirmation which will be needed if you need to contact us about warranty coverage.

Purchase Date: _____



Questions, problems, missing parts?

Before returning to your retailer, our exceptional customer service is available.



BEFORE YOU BEGIN

Before beginning assembly, make sure all parts are present. Compare parts received with the “Parts List.” If any part is missing or damaged, do NOT attempt to assemble the product. Please read and understand this entire manual before attempting to assemble, operate or install this product. If you have any questions regarding the product, please call us toll-free, email us, or go online and live chat.



GENERAL INFORMATION

Your new chair is made from the finest materials available. It should provide many years of enjoyment with minimal care.

Keep your chair clean. For best results, clean the chair with a soft, damp cloth. If you use furniture covers, always make sure the chair is clean and completely dry before covering as mold may form in dark, wet places. Remove cushions prior to covering and store them in a dry, temperature controlled place. Check the hardware on your chair regularly to make sure it is secure.

The weight limit for this chair is 220 lbs.



SAFETY INFORMATION

WARNING


DO NOT stand or allow children to stand on the assembled product.

DO NOT tighten hardware completely until instructed to do so. After final alignment, make sure all hardware is securely fastened. NEVER use a power tool to assemble or tighten your furniture. Perform periodic checks to make sure the hardware is secure and tighten if needed.

CAUTION

READ all instructions before beginning assembly. Failure to do so may result in faulty assembly and potential injury. Assemble the item on a soft, non-abrasive surface such as a carpet or cardboard to avoid damaging the item.


PARTS LIST




PART	DESCRIPTION	QUANTITY
A	Seat Back	1
B C	Arms	2
D	Seat	1



HARDWARE CONTENTS



E
M6x20 Bolts
Qty: 6



F
M6x40 Bolts
Qty: 3



G
M6 Washers
Qty: 9




H
Hex Wrench
Qty: 1

ASSEMBLY

Before you begin, place all parts on a clean, soft, level surface.


- 1** Attach the Arms **B** and **C** to the Seat **D** with 4 Bolts **E** and M6 Washers **G** as shown. Tighten using the Hex Wrench **H**.

Hardware Used: **E** Bolts (6x20mm) x 4
G Washers (6mm) x 4



- 2** Attach the Arms **B** and **C** to the Seat Back **A** by sliding the arms onto the pegs on the sides of the Seat Back, then using a Bolt **E** with a Washer **G** to fasten each Arm as shown. Tighten using the Hex Wrench **H**.

Hardware Used: **E** Bolts (6x20mm) x 2
G Washers (6mm) x 2




ASSEMBLY

- 3** Attach the **Seat D** to the **Seat Back A** using 3 **Bolts F** with **Washers G**, inserted through the **Seat** and into the **Seat Back**. Tighten using the **Hex Wrench H**.

Hardware Used: **F** Bolts (6x40mm) × 3
 G Washers (6mm) × 3

Check all hardware. Your chair is now ready for use!





LIMITED WARRANTY

Customers in the Contiguous US

This product is warranted for a period of 1 year from original purchase date against defects in materials and workmanship under normal use. This warranty does NOT cover normal wear/weathering, exposure to water, freezing temperatures, oils, fluids, or chemicals, OR use in a commercial application if model is not designated as a commercial model. At our sole discretion, products under warranty will be repaired and/or replaced at no charge to the customer. Returns sent back to us must be sent via prepaid freight in the original retail packaging.



Important Notice

Do NOT return to place of purchase—for customerservice andwarranty issues contact our Customer Service Center or go online and live chat.