








Manufacturer and seller expressly disclaim any and all liability for personal injury, property damage or loss, whether direct, indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, or neglect of this product



Please remove the circular protector caps on the end of each of the poles before assembling.


Assemble the Christmas tree.

Note: Make sure sections are arranged in the correct order.


A Christmas tree without lights does not include any electrical components. The ones with lights needs to be compatible with a connector to make the tree sparkle and shine!

**The following is an diagram for reference only!
The final product is subject to the actual one you receive!**


Two kinds power supply:




PARTS




Spread out the branches of the tree and rearrange them to your preference.




Make the innermost tips to be 90° to the branch and between-tips 45°



Make the next layer tips to be 60° to the branch and between-tips 45°



Make the next layer tips to be 45° to the branch and between-tips 45°



Make the outermost tips to be 5 direction as picture, the top one to be 180° to the branch.