



Notice:
1.Follow the installation instructions. Please confirm all accessories are preset beforeinstallation.
2. Do not fully tighten the screws during initial assembly. Fully tighten screws only onceall pieces which are correctly assembled.
3. If you encounter any problems during installation, please contact our customer service
4. Please unbox the item from the side with an open-label and put a carpet on the floor to avoid scratching it.


Recommendedinstallers:2


Put a carpet on the floor before unpacking





Estimate installation time: 20 minutes

Item mo.	Reference Image	Qty
Ⓐ		x1
Ⓑ		x4

Item mo.	Reference Image	Qty
①		x4


1





3

2




4

Cabinet DoorAdjustment Instructions

Height adjustment:

a) Locate the height adjustment screws on the hinge.


b) Use the Phillips screwdriver to either tighten or loosen the screws to raise or lower the cabinet door as desired.



Side-to-side adjustment:

a) If the cabinet door needs to be moved closer to or away from the cabinet frame, locate the side - to-side adjustment screws on the hinge.

b) Use the Phillips screwdriver to adjust these screws and gradually move the door in the desired direction.



Depth adjustment (if applicable):

a) Check if the cabinet door needs to be brought closer to or further away from the cabinet frame.

b) For-depth adjustment, locate the depth adjustment screws on the hinge.

c) Use the Phillips screwdriver to turn these screws clockwise or counterclockwise accordingly.

