

# PORTABLE NEST + STRAP + CEILING MOUNT



**Read all assembly and care instructions carefully before using this product. Save these instructions for future reference.**

- Assemble components on a soft, clean surface to avoid scratching and/or damaging the finish.
- Ensure all parts are accounted for before disposing of packaging.

## ► IMPORTANT INFORMATION

- Before each use, inspect your mount for wear and weakness.
- Ensure the mount is assembled correctly and the hardware is securely tightened before each use.
- Swinging, bouncing, jumping and other excessive movements may cause serious injuries.
- Do not exceed the recommended weight capacity of the mount and straps.

**Any modification or failure to follow the recommended care will void the product warranty.**


## ► WARNING




Manufacturer and seller expressly disclaim any and all liability from personal injury, property damage or loss, whether direct or indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, or neglect of this product.

# PORTABLE NEST + STRAP + CEILING MOUNT


**1** Drill a hole in the ceiling roughly the same diameter as the screw. Drive the screw into the hole until flush with the surface of the ceiling.




**2** Drill a hole in the ceiling roughly the same diameter as the anchor. Hammer the anchor in until flush with the surface of the ceiling. Drive the screw into the anchor.




**3** Attach the straps as desired.



**6** Connect the S-hook onto the desired notch.



**5** Thread the end of the strap through only the second D-ring as shown, pull to tighten.



**4** Thread the end of the strap through both D-rings.

