



**DNT512**


# Part list




① X2




② X2




③ X1




④ X4




⑤ X4




⑥ X2



⑦ X2




⑧ X2




⑨ X2


# Part list




⑩X2



⑪X2




⑫X4




⑬X2


# Hardware list




Ⓐ X1




Ⓑ X8




Ⓒ X36



Ⓓ X4




Ⓔ X12




Ⓕ X16




Ⓖ X8





Ⓗ X8





Ⓘ X1




1




2



3




X2




(C) X20

4






X2




(C) X8

11




① X1

5




X2



6




(E)X8

X2






9



ⒺX2





ⒻX8



ⒼX4

X2

10



ⒼX8

X2