


ASSEMBLY INSTRUCTION













REAR












FRONT




PART LIST

1 Top panel  1pc	2 Bottom panel  1pc	3-L Side Panel(left)  1pc	3-R Side Panel(right)  1pc	4 Division  1pc	5 Back Rail  1pc
6 Back Panel  2pcs	7 Door(Side)  2pcs	8 Door(Center)  2pcs	9 Shelf Panel  2pcs	10 Frame post  2pcs	11 Frame Rail  2pcs
12 Center post  1pc					


HARDWARE LIST




A MINI FIX SPREADING BOLT 24MM  36pcs	B MINIFIX HOUSING Ø15*12MM  6pcs	C MINIFIX HOUSING Ø15*10MM  30pcs	D WOOD DOWEL M8*30MM  32pcs	E CSK SCREW M3.5*12MM  52pcs	F CSK SCREW M4*30MM  16pcs
G SHELF SUPPORT  8pcs	H JCBC M6*40MM  1pc	I DOOR STOPPER  2pcs	J M4 ALLEN KEY  1pc	K HANDLE  4sets	L ADJUSTER  5pcs
M HINGES  4pcs	N HINGES  4pcs				

STEP 1




STEP 2




							
D X 14pcs	F X 4pcs			F X 12pcs	L X 4pcs		

STEP 3



STEP 4





L X 1pc




H X 1pc


J X 1pc






STEP 5



FRONT




STEP 6







STEP 7

FRONT VIEW



REAR VIEW




A X 19pcs

C X 16pcs

D X 6pcs




STEP 8







							
A X 10pcs	C X 10pcs	D X 6pcs					

STEP 9




STEP 10






 E X 16pcs	 M X 4pcs	 N X 4pcs		 G X 8pcs			
--	---	---	--	---	--	--	--

STEP 11




STEP 12



 E X 32pcs				 E X 4pcs	 I X 2pcs	 K X 4sets	
--	---	--	--	---	---	--	---


ASSEMBLY COMPLETE



ASSEMBLY INSTRUCTIONS


How to Concealed Hinges

Height Adjustment-helps you to adjust doors so they align at the top and bottom.




Note: Run your hand along the underside of the doors. You will easily feel which door are sitting lower than the others.

Depth Adjustment- Lets you bring a door into alignment with vertical surfaces such as drawers.



Note: Check to make sure you are not missing a door bumper. Missing door bumpers will cause your cabinet to look out of alignment.

Side Adjustment- adjusts gaps between doors and alleviates rubbing doors.



Note: Right Side Hinge: Clockwise moves door to RIGHT, CCW moves door to LEFT.
Left Side Hinge: Clockwise moves door to LEFT, CCW door to RIGHT.