


Note: Remove the battery insulation tab before first use. Only the Light Adaptor can receive the Light Remote Control signal. Please aim at the adaptor when operating.



1. Automatic cycle lighting
 2. Warm Light on---C1
 3. Colorful light on---C2
 4. 75% C1 & 25% C2
 5. 75% C2 & 25% C1
 6. C1 and C2 gradually change
 7. C1 and C2 breathing change
 8. C1 Slowly flashing
 9. C2 Slowly flashing
 10. C1 and C2 alternate flashing
 11. C1 and C2 wave flashing
- ON:** Power on
Off: Power off
Timer off: Set timer function button;
(Before setting the timer for 6H, 8H, or 6639H, press TIMER OFF.)
6H: 6H (ON) 18H (OFF)
8H: 8H (ON) 16H (OFF)
6639H: 6H (ON) 6H (OFF) 3H(ON) 9H(OFF)

Four Dimmer

100%	75%	50%	25%
------	-----	-----	-----

We promise to provide users with high-quality after-sales service, including but not limited to the following aspects:

1. Provide professional technical consulting services
2. If there is a malfunction due to product quality issues, we will repair or replace the parts for you free of charge.

If there are any problems during the use of the product, please contact us, we are available 24 hours a day.

Before contacting us, please let us know through what channel you get our product and attach the order number for us to easily check the information.
Thank you!

FCC statement:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.


Pop-Up Christmas Tree



Assembly Instruction

Made in china

1. Package Included




Note: If you find any damaged or missing accessories, please contact us immediately.

2. How To Install?

Step 1:


Please check if the accessories are complete and undamaged.

Step 2:




Insert 4 leg stands and the one pole into the center stand.

Step 3:




Insert 3 iron pole into the center stand leg.

Step 4:



Make sure the top of the upper pole going through the iron hole in the middle of the base bar inside the tree.

Step 5:




Put the tip of the upper pole into the cone cap inside the top of the tree body.

Step 6:




Release the tree body, so it stands up.

3. Light Remote Control Instructions



Please find the light string connector at the bottom of the tree body, connect it to the Light Adaptor, and connect the power supply.



Remove the battery insulation tab before first use. Aim remote at the Light Adaptor, press the button according to your own needs.