


ASSEMBLY INSTRUCTIONS

ITEM NO: 4201

This box contains the following items.

- Screen – 1 Pc.
- Feet – 2 Pcs.
- Allen Screws – 2 Pcs.
- Allen Wrench – 1 Pc.

1. This item has two feet which need to be attached using the hardware and tools provided.
2. The feet have been marked A and B. The corresponding locations for these feet are also marked A and B on the bottom of the frame. Match the direction of the letters on the frame and feet.
3. Place screw through foot into frame and tighten with wrench.
4. While fixing the feet do not tighten the Allen screws completely right away. Leave the screws little loose and move the feet to ensure that they settle correctly in the slot for the frame. Gradually tighten both feet ensuring that they are correctly mounted.
5. Stand the screen upright to check that it stands vertical. If required press down gently to achieve proper alignment. You may have to loosen screws on feet to ensure proper fitting if the frame does not stand upright.
6. Tighten the screws completely to finish the assembly.



CARE INSTRUCTIONS

Wipe with a soft, dry cloth. To protect finish, avoid the use of chemicals and household cleaners.